



T/Guard™-408 and -408XT

Fiber Optic Thermometer Systems for Power Transformers

4-, 6-, 8-, 10-, 12- and 16-Channel Versions
With OptiLink-II software

Qualitrol Company LLC / Neoptix Canada LP
1415, rue Frank-Carrel, Suite 220
Québec, QC, G1N 4N7
Canada
Tel: 418-687-2500
Fax: 418-687-2524
support@neoptix.com

Proprietary notice:

Details of design and engineering are the exclusive property of Neoptix Canada LP and Qualitrol Company LLC and are strictly confidential. The information given herein is subject to change, at any time and without notice.

All rights are reserved. The information in this document may not be reproduced or passed on in any manner without prior written consent of Qualitrol Company LLC.

Qualitrol Company LLC shall not be liable for technical or editorial errors or omissions contained herein; nor for incidental or consequential damages resulting from the furnishing, performance, or use of this material.

All trademarks are the property of their respective owners.

Part number: G1044r08 (July 2015)

1 TABLE OF CONTENTS

1	TABLE OF CONTENTS.....	2
2	WARNING.....	5
3	IMPORTANT SECURITY DISCLAIMER	6
4	END USER LICENSE AND SOFTWARE WARRANTY AGREEMENT.....	7
4.1	T/GUARD 408 WARRANTY NOTICE.....	10
5	INTRODUCTION.....	11
5.1	CALIBRATION.....	12
5.2	TRANSFORMER APPLICATIONS.....	12
6	INSTALLATION OF THE T/GUARD 408.....	13
6.1	MECHANICAL INSTALLATION.....	13
6.2	ELECTRICAL INSTALLATION.....	14
6.2.1	Connector Description.....	14
6.2.2	Probe Connections (Extension, Outside Transformer).....	15
6.2.3	Analog Output Connections.....	16
6.3	MATING CONNECTORS.....	17
7	USING THE KEYPAD MENUS.....	18
7.1	THE MAIN DISPLAY MENU.....	18
7.2	THE SETUP MENU.....	21
7.3	THE GLOBAL TEMPERATURE MENU.....	23
7.4	THE MINIMUM – MAXIMUM MENU.....	23
7.5	THE CHANNEL ENABLE MENU.....	24
7.6	THE SIGNALS MENU.....	24
7.7	THE RELAY CONDITION MENU.....	26
7.8	THE RELAY FAILSAFE MENU.....	27
7.9	THE LOGGING MENU.....	27
7.10	THE PROTOCOL MENU (SERIAL).....	28
7.10.1	Neoptix ASCII Protocol.....	29
7.10.2	Modbus Protocol.....	29
7.10.3	DNP 3.0 Protocol.....	29
7.10.4	IEC 60870-5-101 Protocol.....	29
7.11	THE TIME MENU.....	30
7.12	THE ETHERNET MENU (FOR 408XT MODEL ONLY).....	30
8	USING THE WEB INTERFACE (408XT MODEL).....	32
8.1	OVERVIEW.....	32
8.1.1	User Management.....	32
8.1.2	Web Sessions.....	32
8.1.3	Duplicating Custom Configurations between T/Guard 408 Devices.....	32
8.2	NETWORKING THE T/GUARD 408 DEVICE.....	32
8.3	FIRST APPROACH: SETTING UP A PRIVATE NETWORK (STATIC IP).....	33
8.4	WORKING WITH THE INTERNET BROWSER (FIXED IP ADDRESS).....	35
8.5	SECOND APPROACH: SETTING UP DYNAMIC ADDRESS (DHCP SERVER).....	35
8.6	THE T/GUARD 408XT WEB APPLICATION.....	37
8.6.1	Note Concerning the Web Browser Cache.....	37
8.6.2	Login Page.....	38
8.6.3	Configurable Colored Dots in the Web Page Headers.....	39
8.7	WEB PAGES FOR AN ADMINISTRATOR USER.....	40
8.7.1	T/Guard 408XT Home Page.....	40
8.7.2	Status Page (Default View).....	41
8.7.3	Status Page (Raw Ethernet Stats View).....	42
8.7.4	Status Page (Formatted Ethernet Statistics View).....	42
8.7.5	Time Setup Page (and NTP servers).....	43
8.7.6	Labels and Interfaces Page.....	43
8.7.7	Manage Serial Port Protocols.....	44
8.7.8	Manage Ethernet Smart-Grid Protocols.....	45
8.7.9	Configuration Web Page for the IEC 61850 Protocol.....	46
8.7.10	Configuration Web Page for the DNP 3.0 Protocol.....	47
8.7.11	Configuration Web Page for the IEC 60870-5-104 Protocol.....	48
8.7.12	Configuration Web Page for the Modbus Over Ethernet Protocol.....	48

8.7.13	File Transfer.....	49
8.7.14	User Management Page.....	50
8.7.15	Add New User Page.....	50
8.7.16	Modify Main User Role Page.....	51
8.7.17	Modify / Delete Other User Page.....	51
8.7.18	Log Download (and Delete) Page.....	52
8.7.19	Log Viewer Page.....	53
8.7.20	Log Setting Page.....	53
8.7.21	Relay Condition Overview Page.....	54
8.7.22	Relay Setup Page.....	54
8.7.23	Relay Condition Setting Page.....	55
8.7.24	Relay Condition Example.....	56
8.7.25	Event Logging Download Page.....	57
8.7.26	Alarm Management Page.....	58
8.7.27	Optical Channel Parameter Overview Page.....	58
8.7.28	Temperature Channel Setting Page.....	58
8.7.29	Global Probe Parameter Setting Page.....	59
8.7.30	Visual Temperature Page.....	59
8.7.31	TransLife™ Result Page.....	60
8.7.32	TransLife™ Setup Page.....	61
8.8	WEB PAGES FOR A GUEST USER.....	62
8.8.1	Login Page.....	62
8.8.2	Home Page.....	63
8.8.3	Status Page.....	63
8.8.4	Time Setup Page.....	63
8.8.5	Labels and Interfaces Page.....	64
8.8.6	Serial Protocols.....	64
8.8.7	Ethernet Protocols.....	64
8.8.8	Log Download Page.....	65
8.8.9	Log Viewer Page.....	65
8.8.10	Log Setting Page.....	65
8.8.11	Relay Condition Overview.....	65
8.8.12	Relay Status Overview Page.....	66
8.8.13	Event Logging Download Page.....	66
8.8.14	Alarm Management Page.....	66
8.8.15	Temperature Channel Overview.....	66
8.8.16	Global Parameter Page.....	67
8.8.17	Visual Temperature Page.....	67
8.8.18	TransLife™ Results.....	67
9	OPTILINK-II SOFTWARE DESCRIPTION (FOR THE 408).....	68
9.1	INSTALLATION AND INITIAL OPERATION.....	68
9.2	ACQUIRE AND DISPLAY TEMPERATURE DATA.....	69
9.2.1	Data Acquisition, Logging and Graphing Rates.....	71
9.2.2	Graphs.....	71
9.3	OPTICAL CHANNEL SETTINGS TOOL.....	71
9.4	RELAY CONDITIONS TOOL.....	72
9.5	DOWNLOAD FILES TOOL.....	73
9.6	GENERAL PARAMETERS.....	73
9.7	ETHERNET PROTOCOL PARAMETERS.....	74
9.8	SERIAL PROTOCOL PARAMETERS.....	75
9.9	FIRMWARE UPDATE TOOL.....	75
9.10	UPLOAD SETTINGS TOOL.....	75
9.11	TROUBLESHOOTING.....	75
10	APPENDIX A – SOFTWARE UPGRADE VIA WEB INTERFACE.....	77
11	APPENDIX B – EXAMPLE OF A DOWNLOADED STATUS TEXT FILE.....	79
12	APPENDIX C – USING OPTILINK TO COMMUNICATE WITH THE T/GUARD 408.....	81
12.1	USING OPTILINK.....	81
12.2	LOGGING TEMPERATURES IN WINDOWS WITH OPTILINK.....	83
12.3	VIEWING TEMPERATURE DATA IN OPTILINK.....	85
12.4	RECOMMENDED CONFIGURATION, FOR TRANSFORMER APPLICATIONS.....	86
12.4.1	Interpretation of Probe Intensity Results.....	86
13	APPENDIX D – MODBUS COMMUNICATION PROTOCOL.....	88

13.1	CONFIGURING THE MODBUS OPTION.....	88
13.2	SUPPORTED SERIAL TRANSMISSION MODE.....	88
13.3	RTU TRANSMISSION MODE	88
13.4	MODBUS FUNCTION CODE AND REGISTER ADDRESSES	89
	13.4.1 Modbus Protocol Map Registers	89
13.5	MODBUS EXCEPTION CODES.....	93
13.6	MODSCAN EXAMPLES.....	93
13.7	USING MODSCAN OVER ETHERNET.....	94
13.8	MONITORING MULTIPLE T/GUARD 408 SYSTEMS.....	95
	13.8.1 Writing Parameters.....	95
	13.8.2 Data logging.....	96
13.9	USING MODSCAN TRIAL VERSION TO TEST THE MODBUS SERIAL PROTOCOL ON THE 408.....	96
14	APPENDIX E – OPTIONAL RS-485 TO USB CONVERTER	99
15	APPENDIX F – COMMISSIONING PROCEDURE FOR NEOPTIX T/GUARD-408	100
	15.1 INTRODUCTION.....	100
	15.2 REQUIRED TOOLS	100
	15.3 SOFTWARE DOWNLOADS	100
	15.4 TESTING PROBES	100
	15.5 ANALOG OUTPUT TESTING.....	101
	15.6 RELAY TESTING.....	101
	15.7 CONCLUSION.....	101
16	APPENDIX G – SERIAL COMMAND REFERENCE	102
17	APPENDIX H – TIME ZONE LIST	104
18	APPENDIX H – ACRONYMS	107
19	INDEX	108

2 WARNING

High voltages are present inside! Do not open. There are no user serviceable parts inside and opening the enclosure will void the warranty.

Permanent damage may be done to the thermometer if the power supply connections are not done correctly. In particular, do not connect the power input (24 VDC or 110-240 VAC) to any of the analog output connectors. Note that the 4-20 mA analog outputs are self-powered interfaces (by opposition to loop-powered interfaces), and thus do not require any external supply. Maximum loop impedance should be kept at 400 Ω ; internal impedance is approximately 0.7 Ω .

The *T/Guard 408* system has a built-in power supply that accepts 85 - 264 VAC or 110 - 370 VDC.

Take note also that the neutral supply connection is grounded to the *T/Guard 408* enclosure.

Fiber optic probes and extension cables are fragile, and will break if the bending radius becomes less than 1 cm, even temporarily. Furthermore, as the tips of the T2 probes are fragile, please exercise care to:

- **Make sure the last ~1 cm of probes is free standing, and not pressurized by any glue, or by the spacers**
- **Avoid bending the last 1 cm of probes.**

Furthermore, due to the unique construction of the Neoptix T2 type probes, it is important that you avoid applying glue to the last 1 cm of the probes during their installation in transformer windings.

Probe and extension cable breakages are not covered under the standard Neoptix warranty.

To assure cleanliness of optical connectors, keep caps on unused connectors at all time. This is also required during operation, as parasitic light entering via unused connectors into the *T/Guard* module may cause false temperature readings, even on other channels.

The Neoptix *T/Guard 408* product family is CE marking certified.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

3 IMPORTANT SECURITY DISCLAIMER

The Ethernet-enabled models of the *T/Guard 408* do not support Secure Sockets Layers (SSL) encrypted communications and therefore should not be connected directly to the Internet.

By design, all *T/Guard 408* devices are intended to be used in closed wide area networks (WANs), supervised by a qualified network administrator.

4 END USER LICENSE AND SOFTWARE WARRANTY AGREEMENT

PLEASE READ THIS SOFTWARE LICENSE CAREFULLY BEFORE DOWNLOADING, INSTALLING OR USING ANY QUALITROL OR QUALITROL-SUPPLIED SOFTWARE. BY DOWNLOADING OR INSTALLING THE SOFTWARE, OR USING THE EQUIPMENT THAT CONTAINS THIS SOFTWARE, YOU ARE CONSENTING TO BE BOUND BY THIS LICENSE.

The following terms govern your use of the Software except to the extent a particular program (a) is the subject of a separate written agreement with Qualitrol or (b) includes a separate “clickwrap” license agreement as part of the installation and/or download process. To the extent of a conflict between the provisions of the foregoing documents, the order of precedence shall be (1) the written agreement, (2) the clickwrap agreement, and (3) this Software License.

License. Subject to the terms and conditions of and except as otherwise provided in this Agreement, Qualitrol Systems, Inc. or the Qualitrol Systems, Inc. subsidiary licensing the Software, if sale is not directly by Qualitrol Systems, Inc. (“Qualitrol”), and its suppliers grant to Customer (“Customer”) a nonexclusive and non-transferable license to use the specific Qualitrol program modules, feature set(s) or feature(s) for which Customer has paid the required license fees (the “Software”), in object code form only. In addition, the foregoing license shall also be subject to the following limitations, as applicable

- Unless otherwise expressly provided in the documentation, Customer shall use the Software solely as embedded in, for execution on, or (where the applicable documentation permits installation on non-Qualitrol equipment) for communication with Qualitrol equipment owned or leased by Customer;
- Customer’s use of the Software shall be limited to use on a single hardware chassis, on a single central processing unit, as applicable, or use on such greater number of chasses or central processing units as Customer may have paid Qualitrol the required license fee; and
- Customer’s use of the Software shall also be limited, as applicable and set forth in Customer’s purchase order or in Qualitrol’s product catalog, user documentation, or web site, to a maximum number of (a) seats (i.e. users with access to the installed Software), (b) concurrent users, sessions, ports, and/or issued and outstanding IP addresses, and/or (c) central processing unit cycles or instructions per second. Customer’s use of the Software shall also be limited by any other restrictions set forth in Customer’s purchase order or in Qualitrol’s product catalog, user documentation or web site for the Software.

NOTE: For evaluation or beta copies for which Qualitrol does not charge a license fee, the above requirement to pay a license fee does not apply.

General Limitations. Except as otherwise expressly provided under this Agreement, Customer shall have no right and Customer specifically agrees not to:

- (i) transfer, assign or sublicense its license rights to any other person, or use the Software on unauthorized or second-hand Qualitrol equipment, and any such attempted transfer, assignment or sublicense shall be void;
- (ii) make error corrections to or otherwise modify or adapt the Software or create derivative works based upon the Software, or to permit third parties to do the same; or (iii) decompile, decrypt, reverse engineer, disassemble or otherwise reduce the Software to human readable form to gain access to trade secrets or confidential information in the Software. To the extent required by law, at Customer's request, Qualitrol shall provide Customer with the interface information needed to achieve interoperability between the Software and another independently created program, on payment of Qualitrol's applicable fee. Customer shall observe strict obligations of confidentiality with respect to such information.

Upgrades and Additional Copies. For purposes of this Agreement, “Software” shall include (and the terms and conditions of this Agreement shall apply to) any upgrades, updates, bug fixes or modified versions (collectively, “Upgrades”) or backup copies of the

Software licensed or provided to Customer by Qualitrol or an authorized distributor for which Customer has paid the applicable license fees.

NOTWITHSTANDING ANY OTHER PROVISION OF THIS AGREEMENT: (1) CUSTOMER HAS NO LICENSE OR RIGHT TO USE ANY SUCH ADDITIONAL COPIES OR UPGRADES UNLESS CUSTOMER, AT THE TIME OF ACQUIRING SUCH COPY OR UPGRADE, ALREADY HOLDS A VALID LICENSE TO THE ORIGINAL SOFTWARE AND HAS PAID THE APPLICABLE FEE FOR THE UPGRADE; (2) USE OF UPGRADES IS LIMITED TO QUALITROL EQUIPMENT FOR WHICH CUSTOMER IS THE ORIGINAL END USER PURCHASER OR LESSEE OR WHO OTHERWISE HOLDS A VALID LICENSE TO USE THE SOFTWARE WHICH IS BEING UPGRADED; AND (3) USE OF ADDITIONAL COPIES IS LIMITED TO BACKUP PURPOSES ONLY.

Proprietary Notices. Customer agrees to maintain and reproduce all copyright and other proprietary notices on all copies, in any form, of the Software in the same form and manner that such copyright and other proprietary notices are included on the Software. Except as expressly authorized in this Agreement, Customer shall not make any copies or duplicates or any Software without the prior written permission of Qualitrol. Customer may make such backup copies of the Software as may be necessary for Customer's lawful use, provided Customer affixes to such copies all copyright, confidentiality, and proprietary notices that appear on the original.

Protection of Information. Customer agrees that aspects of the Software and associated documentation, including the specific design and structure of individual programs, constitute trade secrets and/or copyrighted material of Qualitrol. Customer shall not disclose, provide, or otherwise make available such trade secrets or copyrighted material in any form to any third party without the prior written consent of Qualitrol. Customer shall implement reasonable security measures to protect such trade secrets and copyrighted material. Title to Software and documentation shall remain solely with Qualitrol.

Term and Termination. This License is effective until terminated. Customer may terminate this License at any time by destroying all copies of Software including any documentation. Customer's rights under this License will terminate immediately without notice from Qualitrol if Customer fails to comply with any provision of this License. Upon termination, Customer must destroy all copies of Software in its possession or control.

Customer Records. Customer grants to Qualitrol and its independent accountants the right to examine Customer's books, records and accounts during Customer's normal business hours to verify compliance with this Agreement. In the event such audit discloses non-compliance with this Agreement, Customer shall promptly pay to Qualitrol the appropriate licensee fees.

Export. Software, including technical data, may be subject to U.S. export control laws, including the U.S. Export Administration Act and its associated regulations, and may be subject to export or import regulations in other countries. Customer agrees to comply strictly with all such regulations and acknowledges that it has the responsibility to obtain licenses to export, re-export, or import Software.

U.S. Government End Users. The Software and associated software documentation qualify as "commercial items," as that term is defined at 48 C.F.R. 2.101, consisting of "commercial computer software" and "commercial computer software documentation" as such terms are used in 48 C.F.R. 12.212. Consistent with 48 C.F.R.12.212 and 48 C.F.R. 227.7202-1 through 227.7202-4, Licensee will provide to Government end user, or, if this Agreement is direct Government end user will acquire, the Software and software documentation with only those rights set forth herein that apply to nongovernmental customers. Use of this Software and software documentation constitutes agreement by the government entity that the computer software and computer software documentation is commercial, and constitutes acceptance of the rights and restrictions herein.

Limited Warranty. Qualitrol Systems, Inc. or the Qualitrol Systems, Inc. subsidiary licensing the Software, if sale is not directly by Qualitrol Systems, Inc. ("Qualitrol") warrants that commencing from the date of delivery to Customer and continuing for a period of the longer of (a) ninety (90) days or (b) the period set forth in the Warranty Card accompanying the Product (if any): (a) the media on which the Software is furnished will be free of defects in materials and workmanship under normal use; and (b) the Software substantially conforms to its published specifications. The date of shipment of a Product by Qualitrol is set forth on the packaging material in which the Product is shipped. Except for the foregoing, the Software is provided "AS IS". This limited warranty extends only to the Customer who is the original licensee. Customer's sole and exclusive remedy and the entire liability of Qualitrol and its

suppliers under this limited warranty will be, at Qualitrol or its service center's option, repair, replacement, or refund of the Software if reported (or, upon request, returned) to the party supplying the Software to Customer, if different than Qualitrol. In no event does Qualitrol warrant that the Software is error free or that Customer will be able to operate the Software without problems or interruptions. In addition, due to the continual development of new techniques for intruding upon and attacking networks, Qualitrol does not warrant that the Software or any equipment, system or network on which the Software is used will be free of vulnerability to intrusion or attack.

Restrictions. This warranty does not apply if the Product (a) has been altered, except by Qualitrol, (b) has not been installed, operated, repaired, or maintained in accordance with instructions supplied by Qualitrol, (c) has been subjected to abnormal physical or electrical stress, misuse, negligence, or accident; or (d) is licensed, for beta, evaluation, testing or demonstration purposes for which Qualitrol does not receive a payment of purchase price or license fee.

DISCLAIMER OF WARRANTY. EXCEPT AS SPECIFIED IN THIS WARRANTY, ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS, AND WARRANTIES INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTY OR CONDITION OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, NONINFRINGEMENT, SATISFACTORY QUALITY OR ARISING FROM A COURSE OF DEALING, LAW, USAGE, OR TRADE PRACTICE, ARE HEREBY EXCLUDED TO THE EXTENT ALLOWED BY APPLICABLE LAW. TO THE EXTENT AN IMPLIED WARRANTY CANNOT BE EXCLUDED, SUCH WARRANTY IS LIMITED IN DURATION TO THE WARRANTY PERIOD. BECAUSE SOME STATES OR JURISDICTIONS DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, THE ABOVE LIMITATION MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM JURISDICTION TO JURISDICTION.

This disclaimer and exclusion shall apply even if the express warranty set forth above fails of its essential purpose.

Disclaimer of Liabilities. IN NO EVENT WILL QUALITROL OR ITS SUPPLIERS BE LIABLE FOR ANY LOST REVENUE, PROFIT, OR DATA, OR FOR SPECIAL, INDIRECT, CONSEQUENTIAL, INCIDENTAL, OR PUNITIVE DAMAGES HOWEVER CAUSED AND REGARDLESS OF THE THEORY OF LIABILITY ARISING OUT OF THE USE OF OR INABILITY TO USE SOFTWARE EVEN IF QUALITROL OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

In no event shall Qualitrol's or its suppliers' liability to Customer, whether in contract, tort (including negligence), or otherwise, exceed the price paid by Customer. The foregoing limitations shall apply even if the above-stated warranty fails of its essential purpose.

BECAUSE SOME STATES OR JURISDICTIONS DO NOT ALLOW LIMITATION OR EXCLUSION OF CONSEQUENTIAL OR INCIDENTAL DAMAGES, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

The Warranty and the Software License shall be governed by and construed in accordance with the laws of the State of New York, without reference to principles of conflict of laws, provided that for Customers located in a member state of the European Union, Norway or Switzerland, English law shall apply. The United Nations Convention on the International Sale of Goods shall not apply. If any portion hereof is found to be void or unenforceable, the remaining provisions of the Warranty and the Software License shall remain in full force and effect. Except as expressly provided herein, the Software License constitutes the entire agreement between the parties with respect to the license of the Software and supersedes any conflicting or additional terms contained in the purchase order.

If Customer has entered into a contract directly with Qualitrol for supply of the Products subject to this warranty, the terms of that contract shall supersede any terms of this Warranty or the Warranty Card, or the Software License, which are inconsistent with that contract. Customer acknowledges that the Internet URL address and the web pages referred to in this document may be updated by Qualitrol from time to time and the version in effect at the date of delivery of the Products to the Customer shall apply.

4.1 *T/GUARD 408 WARRANTY NOTICE*

Your *T/Guard 408* unit is guaranteed (Parts and Workmanship) for one full year from the date of purchase. Upon written notification of any defect, Neoptix will either repair or replace any faulty product or components thereof. A Return Authorization Number (RMA) must be obtained from Neoptix Canada LP or authorized distributor prior to any merchandise return.

Due to the unique nature of the fiber optic material that is used with the *T/Guard 408* systems, probes and extension cables are not warranted.

When using any electrical appliance, basic safety precautions should be followed, including the following:

- Do not operate in wet / damp environments
- Do not operate in explosive atmospheres
- Keep product surface dry and clean.

Always make sure all electrical installations are made in accordance with local authorities' regulations and laws.

5 INTRODUCTION

The Qualitrol® *T/Guard 408*™ is a multichannel fiber optic temperature monitoring system optimized for power transformer hot spot measurements. It has been developed with long-term performance and stability in mind. This fiber-optic temperature monitoring system for power transformers offers accuracy, toughness, ease of use and long-term resistance to failure.

Coupled with the *T/Guard 408* system, the Neoptix T2 fiber-optic temperature probes provide accurate and direct temperature monitoring of transformer windings. It can also be used with T1 type probes. This solution provides a realistic, real-time view of winding conditions that is quicker and more accurate than WTI (Winding Temperature Indicator) top oil thermocouple measurements, and greatly complements indirect measurements based on thermal models.

Since its inception, Neoptix, part of the Qualitrol / Danaher family, has developed expertise in monitoring temperatures of hot spots in power transformers, and is considered a world leader in this field. Our user guide called, "*Probe Installation Guide, inside power transformers*" (part number G1009rXX) should be used by transformer manufacturers as a guide to safely install the probes inside windings of a power transformer. Make sure you instruct all of your employees that fiber optic components, contrary to conventional copper wires, are fragile. Generally speaking, fiber optics, contrary to copper wires, cannot be repaired once broken!

The Qualitrol® *T/Guard 408* gives the exact temperature of optical probes in as little as 250 milliseconds per channel. Peak loads or emergency overloads are thus detected almost instantaneously. The *T/Guard 408* system is specifically designed to meet power transformer industry requirements: extended intervals between servicing, low maintenance, rugged components and the ability to withstand the harshest conditions. All components have been specifically selected for long term performance, including the light source that has an MTBF far superior (>300 years) to the expected life of the transformer. Moreover, our sensor, based on solid-state semiconductors, does not fade or drift over time, allowing a constant and absolute temperature measurement of your transformer windings over the lifespan of the equipment.

Qualitrol fiber-optic probes are based on the proven GaAs technology and made only with dielectric materials. They are designed to withstand initial manufacturing conditions, including kerosene desorption and heat runs¹, as well as long term oil immersion and vibration.

The *T/Guard 408* system is available with 4, 6, 8, 10, 12 or 16 optical channels. There is one four-digit high powered LED display for each channel², allowing a clear view in day time to someone standing at a good distance from the device. A total of 8 channels can be displayed simultaneously; for systems with more than 8 channels, readings are alternating. Signal conditioner power consumption of the system is 30 watts with all relays enabled.

The *T/Guard 408* can be mounted in the back of a control cabinet using 4 screws or mounted directly on the cabinet swing door using the four bolt anchors. It comes standard with a built-in data logging memory (2 or 4 GB) that allows utilities and transformer operators to record temperature data points and alarm status information directly into their *408* temperature monitoring system, without the need for permanent connection to a remote acquisition system. The memory available will allow for many years of data logging of all channels once every minute. Moreover, data points are saved with a time stamp that comes from the internal real-time clock. The information can be accessed through serial port (on the *408* model) as well as through any web browser (on the *408XT* model).

The *T/Guard 408* system provides an easy to use interface to an existing SCADA or substation system through its 4-20 mA analog outputs or through its RS-485 serial port using the Modbus protocol or DNP 3.0 serial or IEC 60870-5-101. A new OptiLink-II software package is now offered to make parameter entry much easier than using the built-in keypad.

The *408XT* version is Ethernet / Smart Grid ready and optionally incorporates, among others, the IEC-61850 protocol and Modbus over Ethernet. Information collected by the system can also be accessed through any web browser over TCP/IP. For this version, parameter entry is very friendly due to the built-in web server interface. Fiber communication is also possible, using the recently developed 100 Base-FX communication option; multimode 50 or 62.5 micron fiber communication is supported; distances of up to 2 km are possible.

¹ Also called "Temperature Rise Test".

² Systems with more than 8 channels toggle between banks of 8 channels on the LED display.

With its small footprint, the 408 is a space-efficient and versatile instrument. All connections are made through detachable Phoenix terminal blocks for easy and seamless installation and after-sales service.

The *T/Guard 408* system has eight built-in Form-C (SPDT) industrial relays with galvanic isolation that can also be set up as Form-A or Form-B relays by user. The system has a fail safe mode whereby relays can be activated in case of a system problem. The latest release (Generation 2, also called Gen-2) of the *T/Guard 408* also includes a dedicated 9th Form-A relay called 'System Fault Relay'.

The system's configuration is made through its industrial grade front panel keypad, serial terminal, PC software (OptiLink and OptiLink-II for the 408 model without Ethernet) or the built-in web-based server (408XT model).

The *T/Guard 408* is a third generation product, designed to replace older systems such as the *T/Guard+*.

Here is a picture of the 408 product, 16 channels.



5.1 CALIBRATION

Your *T/Guard* thermometer comes factory-calibrated. Experience has shown that re-calibration is not required over the whole product life; however, if your ISO rules state that an annual re-calibration is required, then it is your responsibility to comply with those rules. For laboratory applications, a new calibration is standard every 12 months or whenever performance verification indicates that calibration is necessary; NIST traceable calibration certificates are available. All calibrations are performed at the factory. Contact your Neoptix Representative for further information.

5.2 TRANSFORMER APPLICATIONS

One of the main applications for the *T/Guard* product is monitoring temperature of hot spots in power transformers. Since its inception, Neoptix has developed expertise in this application, and is considered as a world leader in this field. Sister products of the *T/Guard 408*, the *T/Guard*, *T/Guard2*, *T/Guard Link*, *T/Guard 405*, are fully dedicated to the power transformer industry. Neoptix publishes a User Guide, called "Probe Installation Guide", totally dedicated to the power transformer industry; do not hesitate to ask for your copy if you are working in this field (Neoptix document G1009).

6 INSTALLATION OF THE T/GUARD 408


Information: Neoptix also published a Quick Startup Guide for the 408; you are encouraged to read this short document first. Reference document number is G1027Rxx

This chapter provides an overview of both the electrical connections and of the fiber connection to a T/Guard 408 system.


6.1 MECHANICAL INSTALLATION

The following drawing gives all mechanical dimensions that would be required to install the *T/Guard 408*, either on a swing panel, or on a mounting plate.

Mechanical details for the 4 to 8 channel version are shown below (dimensions are given in mm and inch). The 100-Base-FX fiber communication option is also shown.




Mechanical details for the 10 to 16 channel version (only height view is shown, as other dimensions are the same as for the 8-channel version, shown above):



Display multiplexing details for the 10 to 16 channel version: There are 2 LEDs on top of each of the 8 displayed values; when channels 1 to 8 are displayed, the LED on the left is lit, and when channels 9 to 16 are displayed, it will be the right LEDs that will be lit.

This second drawing, below, could be useful especially if you mount the unit on a swing panel, as it gives the details of the required cutout hole for such installation. Furthermore, details on the required bolts are given (M6 or M8).



6.2 ELECTRICAL INSTALLATION

Mating connectors (terminal blocks) for the 85-260V AC power, relays and the Analog Output connectors are supplied with the system (Phoenix series "COMBICON FRONT-MSTB" connectors, or equivalent).


6.2.1 CONNECTOR DESCRIPTION

See figure below for a full description of all electrical connectors that are on the 408 instrument. Take note that this drawing may include some options that are not included in your specific system. Take note that the Ethernet port is present only for the XT version of the 408.

The second generation of the 408 instruments (manufactured after December 2012, also called Gen-2) have a 'System Fault Relay'. This special 2-contact relay (also referred to as a Form-A relay) is 'hard wired' and not programmable by the user; it is activated or energized when the 408 is running normally. There is one notable exception: at power on, the System Fault Relay becomes active

only after a period of about 25 seconds, which corresponds to the time period it takes for the 408 internal electronic to become responsive; if this is not acceptable for your installation, then you should think about using a time delay relay in series with the 408 System Fault Relay. Also, any reboot of the 408 instrument will generate a fault that will last about 10 seconds.

The 408 instrument has 8 built-in relays. These relays are completely general purpose, and are fully programmable by the user. These are C-form relays, with a common terminal, a no (no = normally open) terminal and a nc (nc = normally closed) terminal. Please note that these relays are forced to stay in their non-energized state for a period of about 20 to 30 seconds after the 408 is powered up, during the time the internal electronic becomes responsive (boot up time).



Note 1
 Input voltage: 85-265 VAC (47-63 Hz)
 or 110-375 VDC
 Connector: Phoenix # 1777293 or equivalent



Note 2
 8 or 16 Analog output 4-20 mA
 (one per channel)
 Total max impedance: 400 Ohms per channel
 Connector (2 or 4) : Phoenix # 1777345 or equivalent.




Note 3
 Serial Port
 Connector: Phoenix # 1777316 or equivalent



	RS485 2W	RS485 4W
1	GND	GND
2	TX/RX a	TX+
3	TX/RX b	TX-
4	TX/RX a	RX+
5	TX/RX b	RX-

Note 5
 8 Form C relays. 8 A, 250 VAC. 8 A, 30 VDC
 Connector: Phoenix # 1777387 or equivalent
 (See chart below)



Note 4
 Close if system is up and running
 Connector: Phoenix # 1777280 or equivalent



Note 6
 100 Base-FX comm. option
 ST connectors (2)
 For 50 or 62.5µMM fiber

Note on wiring
 Shielded cables are recommended.
 Shield should be grounded at one end only, preferably at the T/Guard end.

The above figure shows the 2 ST connectors that will be available only when the -FX option (100 base-FX communication) is installed; when installed, this option allows the user to communicate via Ethernet using multimode (50 or 62.5 µ) fibers. Selection of Ethernet using the RJ45 connector (100BASE-TX) or the ST connectors (100BASE-FX) must be done via the keypad (also possible with OptiLink-II or the web server); please refer to information given in Section 7.12 for the keypad use. The Neoptix -FX option complies with the IEEE 802.3u standard. Please note that only one Ethernet link can be active at any given time.

6.2.2 PROBE CONNECTIONS (EXTENSION, OUTSIDE TRANSFORMER)

Cautions:

- For maximum fiber cable life, it is important that no part of any fiber optic cable be exposed to direct sunlight, as this can cause the cable to prematurely age. Animals can also damage fiber cables.
- Do not pull the fiber optic cable through the conduit by using the connector.

- When pulling the fiber optic cable through junction boxes, do not bend the cable less than 25mm (1 inch) radius. Oversized junction boxes are preferred.
- When pulling the fiber optic cable through a conduit, make sure the red or transparent PVC caps are covering the cable ends.
- The connector ends must be cleaned prior to final connection to remove debris that may have collected during installation. Debris can block the passage of light down the fiber. To avoid this, please follow the following procedure:
 - Use optic-grade wipes and optic grade 99% isopropyl alcohol OR *Optic Prep pads*.
 - Gently wipe the ferrule (and especially the end) in a circular motion
 - Allow 10 seconds for the alcohol to evaporate.

Warning: Make sure all unused connector inputs are blocked with dust caps, to prevent any spurious light from entering the thermometer, as this can cause false temperature readings on other channels.

Align the “key” on the connector with the slot on the mating sleeve, slide connector into sleeve and gently rotate the connector body while pushing towards the mating sleeve until the “keys” on the mating sleeve slide into place. This is similar to a bayonet or BNC type connector.

To install external fiber optic extension cables, follow this procedure:

1. Make sure the red or clear-colored caps supplied with the cables are installed at each end of each cable, and this for the whole installation process.
2. Tape the pull wire at least 15 cm of the outside fiber optic cable, and then pull the cable through the conduit.
3. Connect all cables to the *T/Guard 408* system and at the transformer tank interface.
4. Store all excess fiber optic cables in 25 cm (or more) diameter loops inside the *T/Guard 408* enclosure.

To ease installation, the Neoptix extension cables are fitted with user-writable sleeves (one at each end) that can be used to help identify the extension cables; this is useful to identify “which cable is which” once many have been installed in the same conduit.

Warning: Do not cross-connect extension cords; this may compromise your system behavior!

For more information, please refer the Neoptix ‘Probe Installation Guide’, document #g1009; to get a copy, please ask your Neoptix representative.

6.2.3 ANALOG OUTPUT CONNECTIONS

There are a total of up to 16 analog output connections, one for each optical channel. Prior to shipment, your *T/Guard 408* thermometer was factory set to 4-20 mA output. The minimum analog output value corresponds to minus 100 °C and the maximum analog output value corresponds to 300 °C. The thermometer’s normal range is from minus 50 °C to 200 °C, so a minimum value indicates an under-range error; likewise, a maximum value indicates an over-range error condition. If the output toggles between the minimum and maximum values, at approximately 0.5 Hz, this indicates a sensor problem for that channel; this default behavior can be changed to force the output to 4 mA (cold situation) or 20 mA (hot situation).

Warnings:

- 1- Do not connect any external voltages to these outputs; this may cause permanent damage to the *T/Guard 408* unit.

2- Avoid shorting together output leads together, as this may destroy the electronic drivers inside the unit.

It is possible to change the Zero and Span from their default -100 °C and 400 °C. With the 408, you can also use either the OptiLink or the OptiLink-II programs to set these parameters; with the 408XT version, you can also use the web server pages.

When using long wires to the analog outputs (4-20mA), it is recommended to use shielded twisted pairs, size AWG 24 or 22. The shield should be grounded at one end only, preferably at the *T/Guard 408* end.

When the instrument is powered up, the analog outputs are forced to stay at their minimum values (4mA) until the internal electronic is up and running, which takes about 25 seconds.

6.3 MATING CONNECTORS

The mating connectors (terminal blocks) are supplied with the instrument. In case you need to get additional terminal blocks, here are the Phoenix Part Numbers.

Function	Number of contacts	Phoenix part number
Power in (AC)	3	1777293
Analog Outputs	16	1777345
RS-485 port	5	1777316
Relay outputs	12	1777387
Fault relay	2	1777280

Phoenix Contact website: <https://www.phoenixcontact.com/online/portal/us>.

7 USING THE KEYPAD MENUS

Before we describe the use of the 4-button keypad, you need to realize that Neoptix offers the following tools to allow you to enter the various parameters that you will need to enter into your *408* before it is ready for use. The keypad is only one of many, and it is probably the most difficult tool of all the tools. In a nutshell, the following are available, starting with the friendliest tool:

- The web server; this option is not available for the *408*, but only for the *408XT*
- The OptiLink-II software tool. This new software tool can make the task of parameter entry much easier; you are highly encouraged to use it; see chapter 9 for a complete description. Contact Neoptix to get the latest version; downloadable from the Neoptix website (www.neoptix.com).
- The keypad, described in this chapter.
- This Chapter deals with the basic software operation of your *T/Guard 408* instrument, through its main LED display and 4-button keypad. Again, if you are using the *T/Guard 408XT* instrument, with an Ethernet connection, it is highly suggested that you read the Quick Start Guide (G1027Rxx), to learn how to connect to the Ethernet.

The *T/Guard 408* has four buttons under its display, from left to right they are:

- The **MENU** button, the **OK** button, the **DOWN** arrow button and the **UP** arrow button.

With these buttons, you will be able to directly obtain and set various device configuration settings. Here is how.

The **OK** button can also be used to acknowledge (and clear) all un-acknowledged alarms, as indicated by the red LED. Note that an alarm acknowledge has no effect on the information stored in the event log file.

7.1 THE MAIN DISPLAY MENU

Before beginning, please note that any operation begun on the LED menus will time out and return to displaying temperatures after about 30 seconds, so if you accidentally make a mistake, just wait a few moments and you will be able to try again with no harm done.

It is also important to note that the default settings of the device are normally just fine for most cases and are based on engineer recommendations, so you should modify settings only if you are sure.


To get started, click on the left-most MENU button. This is the entry point to all the different functionalities provided through the display. The sub-menus for these functionalities are:

- Setup
- Temperature
- Minimum Maximum Temperatures per channel
- Channel Status (Enabled/Disabled)
- Signals (Min/Max Ratio, Lamp power, CCD time and power %)
- Relay Condition
- Relay Failsafe
- Logging
- Protocol
- Ethernet (model *408XT* only).


You can cycle through these sub-menu selections and back again to the temperature display by clicking on the MENU button repeatedly.

If you enter one of the sub-menus, you can always get out of them without making any permanent changes by clicking the MENU button.

This page provides a diagram of the sub-menus for the 408 model (no Ethernet):



This page provides a diagram of the sub-menus for the 408XT model (with Ethernet):



7.2 THE SETUP MENU


This menu provides information about:

- the device's internal software version; there is nothing to set here, this is information that would be useful only if you were to place a support call;
- whether there is a second calibration of temperatures; this depends on whether the fiber optic probes are legacy (Nortech Fibronic probes), in which case: "enabled", or not: "disabled";
- the number of times a temperature is held internally before displaying "not available"; normally there is almost never any need to change this value (for transformer applications, 5 is recommended);
- whether Wtune is enabled or not (for transformer applications, this should be enabled) (maximum sensitivity is obtained with Wtune enabled, at the expense of a slower acquisition speed);
- whether temperatures are displayed in degrees Fahrenheit or Celsius;
- whether the serial port is set for half or full duplex (this can be controlled by software, but must match associated hardware and wiring adjustments);
- the interval of time (for *T/Guard 408* devices with more than 8 channels) between the presentation of channels 1 to 8 (bank 1) on the display and the presentation of the remaining channels (bank 2), from 1 to 8 seconds;
- whether the serial communication is functioning properly (visual test using a LED). When activated, the "Alarm" LED will flash temporarily when ASCII characters are received or sent on the RS-485 serial port. This will work with all serial protocols (ASCII, Modbus, DNP 3 and IEC 61870). This feature is disabled automatically when the electronic reboots.


If you change the temperature unit while the device is set to save temperatures to a log file, then a new log file will be started with the new correct unit and the old log file will be archived. This ensures the correct temperature unit is displayed in the log headers at all times.

Either the current log file or the archived log file(s) can be retrieved by file download.

Here are schematics of the various menus (next page):



7.3 THE GLOBAL TEMPERATURE MENU




There is nothing to set in the Temperature menu.

The High Global value displayed here indicates the highest temperature that was observed on the device, and on which channel it was observed on.

Respectively, the Low Global value will indicate the lowest temperature that was observed, and on which channel it was observed on.

The High Global and Low Global indicate values since the device's last restart.


7.4 THE MINIMUM – MAXIMUM MENU



Here, you can view at a glance what the minimum and maximum temperatures measured were for each available channel.

Minimum and maximum temperatures are calculated based on the set of temperatures encountered since the device was rebooted or reset; each optical channel has its associated minimum and maximum values. If you wish to reset the minimum and maximum values without restarting the device, you simply need to navigate to the "Reset All" menu item and click the OK button. This will return you to the base menu at the "MIMA" menu position.


7.5 THE CHANNEL ENABLE MENU



In this menu, you can enable or disable a channel from displaying a temperature. You might want to do this if a fiber optic probe was not hooked up (values for this channel do not apply) or if a probe was broken along the way and thus the displayed temperature is known to be incorrect.

A disabled channel has its corresponding display as blind (i.e. is left blank).

7.6 THE SIGNALS MENU



There is nothing to set in the Signals menu.

Here, you can view at a glance the minimum/maximum ratio (multiplied by 100), lamp power index and CCD (length of exposure to light in milliseconds) for each available channel.

When you select the "SiGS" sub-menu by clicking the OK display button, the first channel will be displayed preceded by an "r" for ratio, so you don't confuse this menu with another.

The "CH1" will blink to indicate you can navigate to the other channels with the UP or DOWN buttons.



Respectively, after the channel number will be the ratio value (preceded with an *r*), the lamp power value (preceded by an *L*) and the CCD value (in msec) (preceded by a *C*). Firmware version 3.72 also adds on the second LED line the Power % value (preceded with a


P), ranging from 0 to 100%; this parameter is a sort of amalgamation that simplifies the interpretation of optical signal strength³. See Section 12.4.1 for a detailed discussion regarding the interpretation of these parameters.

Hint: If the power percent value is not displayed (“P 100” in above example), this means that the parameter “wtune” is not currently enabled. Refer to Section 7.2 to enable wtune.

At any time, you can exit the SIGNALS menu by clicking the left-most MENU button.

³ For oil-filled power transformer application, experience has shown that this reading be at least 100% for a probe alone, and a minimum of 65% when testing a probe connected to OFT feedthrough and extension cable (at room temperature).

7.7 THE RELAY CONDITION MENU




The Relay Condition menu is the most complex of the menus, with a logic path five-level deep. This allows you to set conditions that will trigger a relay, and by extension an automated process, when the desired conditions are met.

An example of a relay condition could be something like, “if channel number X’s temperature rises above temperature Y, then set off relay number Z”, where X, Y and Z are all numeric values than can be chosen and set. Here “above” means the same as “greater than”.

The system support up to 128 settable conditions, each one can be enabled or disabled. Because setting all these conditions on the display could become quite a chore, there are alternatives: more user-friendly ways are provided by the *T/Guard 408* to set relay conditions. The *408XT* model also offers a third alternative: a web interface where conditions can be set.

Each relay condition can be either logged and each condition can be flagged as an alarm condition. There are three possible combinations of event logging and alarm: DISABLED (no logging, no alarm); ENABLED (with logging, but no alarm) and ALARM (with logging and alarm). An alarm is always logged.


7.8 THE RELAY FAILSAFE MENU



This menu will allow you to set whether a given relay is normally open or normally closed.

It can be used for example in combination with relay condition settings to turn something either on or off when a condition is reached.

7.9 THE LOGGING MENU



By default out of the box, the *T/Guard 408* logs once every 10 minutes.

To reduce internal file I/O on the internal disk media, it is possible to turn off logging completely using this menu here.


In general, it is recommended to leave the data logging on using a logging rate of 10 minutes or more (except for heatrun tests (temperature rise tests), where 1 or 2 minute intervals are recommended).

Please note that if you reduce the logging rate to less than once per minute, and the device is restarted, that logging rate will automatically be reset to one per minute by design. This is because a logging rate this frequent is considered an extraordinary value, probably only to be used in the case of an emergency and undesirable in the long run (after the emergency is over).

7.10 THE PROTOCOL MENU (SERIAL)

If you have purchased the serial protocol package, the following protocols will be available to you (the Modbus and Neoptix ASCII protocols are always included with the basic instrument package; however, this menu allows configuring them):

- o Neoptix ASCII protocol (required for OptiLink, OptiLink-II and HyperTerminal or equivalent)
- o Modbus
- o DNP 3.0
- o And IEC 60870-5-101.



This menu is exclusively for protocols that communicate through the serial port.

There are some restrictions on the combination of parity and stop bits that can be set depending on the protocol you want to use; illegal combinations of baud rate, stop and parity bits are not selectable.

Warning: Switching from one protocol to another will render a currently-connected client useless you when you disconnect it and reconnect again. Disconnecting an application can be confusing, so be careful when you make changes here.

Warning: Your external wiring can be done in half-duplex (2 wires) or full duplex (4 wires); in all cases, make sure the software setting is matching your hardware. For the 408, please refer to section 7.2.

Neoptix has published a separate guide on protocols, # g1030; do not hesitate to ask for your copy.

7.10.1 NEOPTIX ASCII PROTOCOL

For backward compatibility with other Neoptix products, the Neoptix ASCII protocol is at baud rate 9600, Parity None, Stop Bits 1. Although this baud rate can be tweaked at run time to make a file download or upload faster (see *Troubleshooting* section for a how-to concerning this), such a change is strictly temporary and non-persistent: the baud rate for this protocol is always set to 9600 at boot time.

This selection is necessary to use software such as OptiLink, OptiLink-II, HyperTerminal and Tera Term.

7.10.2 MODBUS PROTOCOL

For Modbus, baud, parity and stop bits settings are configurable. Please note however that as per the protocol's specifications, only some combinations of these settings are allowed:

- Parity even, 1 stop bit
- Parity odd, 2 stop bits
- Parity none, 2 stop bits (1 stop bit is also accepted, but this in principle does not comply with the standard).

The Modbus protocol also has an Address ID value (also called *Node address*) that indicates the device's position, i.e. where it is daisy chained (or networked) with other devices. Valid ID addresses are from 1 to 247 (up to 255 is tolerated).

Please refer to "APPENDIX D - Modbus communication protocol", chapter 13, for the complete reference regarding this protocol. Document G1030, Smart Protocol Reference Guide, can also be a very useful reference document; do not hesitate to ask you copy from Neoptix.

7.10.3 DNP 3.0 PROTOCOL

For DNP 3.0, the baud rate is modifiable. Parity is fixed at *None* and Stop bit is fixed at *1* as per protocol specifications. Master station address by default is *65500* and secondary station address (or 408 slave address id) by default is *1*. It is recommended to keep these default values. If you need to change them, however, it is possible through the *Labels and Interfaces* web page on the 408XT model or (on all models) through the following Neoptix protocol serial commands:


```
master:XXXXX .. Define DNP 3.0 master station address (normally 65500)
second:XXXXX .. Define DNP 3.0 secondary (slave, the 408 here) station address (normally 1)
```

7.10.4 IEC 60870-5-101 PROTOCOL


For IEC 60870, baud rate and address id are modifiable. Parity is fixed at *Even* and Stop bit is fixed at *1* as per protocol specifications.

7.11 THE TIME MENU

The time menu can be used to initialize the 408 clock. It can be used to set the time zone, the date and the time. Please note that if the NTP server is active, the Ethernet will overwrite any date and time entries that you may have made here.



7.12 THE ETHERNET MENU (FOR 408XT MODEL ONLY)



Remember that you need a live Ethernet connection for the following to function properly. The network connection is normally established by the device at boot time, right after the start of the main temperature acquisition and display program.

The blinking IP submenu immediately displays the current IP address, alternating with “EtHE AddrESS” (Ethernet address).

From this submenu, click the UP or DOWN button to go to the IP submenu. The currently selected configuration will also be displayed: i.e. either dynamic DHCP or the Static IP preset of 10.0.0.4.

The DHCP submenu is intended to help you to resolve networking difficulties with the device, the most common being a badly configured static IP address which makes the device unresponsive over the network. This could be caused by a bad gateway setting or an IP address out of allowed range set on the device. If “DHCP no connect” is displayed, check your cabling first!

The DHCP submenu allows you to either:

- reset an incorrect static network setting back to dynamic DHCP, or
- configure the device to the factory default preset static IP address that will allow you to connect a computer or notebook directly to the device using a special cable, in the case where no DHCP server is present. This preset address is:
IP address: 10.0.0.4
Netmask: 255.255.255.0
Gateway: 10.0.0.1

If you do not like these settings, you *must* first connect using these default values, then go to the web pages and enter the addresses that you want.

If your 408 is fitted with the FX option (100 Base-FX), this menu allows you to choice between the RJ45 copper Ethernet or the FX fiber Ethernet; you should select the one you intend to use. Please note that if you are connected to one type, the other one is automatically disabled.

A change in IP address or in the Ethernet port selection will force a system reboot.

8 USING THE WEB INTERFACE (408XT MODEL)

8.1 OVERVIEW

The web application provides the same functionalities as through the serial port, and more, and the Ethernet connection is tens of times faster on a regular network than through the serial port.

8.1.1 USER MANAGEMENT

The *T/Guard 408XT* allows the creation of up to 10 users, each with their own login and password to the web application, with either a “guest” role or an “administrator user” role. An “admin” user can update configurations and a “guest” user can only view data. This convenience allows:

- Providing temporary limited access to the device various personnel without having to vehicle sensitive passwords; a new user can be set up as a guest quickly and the login can be deleted a short time later.
- Distributing responsibility between more than one manager while maintaining basic security;

8.1.2 WEB SESSIONS

A web session is unique to a single user on a single computer on a single browser. If there is no action for 15 minutes, the web session times out and the user will need to log on again to resume. As many as 25 concurrent sessions can be open simultaneously; each session can have its own language selection; however a new session always starts in English.

8.1.3 DUPLICATING CUSTOM CONFIGURATIONS BETWEEN T/GUARD 408 DEVICES

No more taking notes and having to remember what you configured on an identical device a few months ago.

On the *T/Guard 408*, it's as easy as downloading a file from one device and uploading the downloaded file to a second device, then restarting the second device. See Section 8.7.13.

Temperature units, relay conditions, second calibration, offsets and many other preferences can be instantly carried over this way from one *T/Guard 408* to the next for zero rework.

8.2 NETWORKING THE T/GUARD 408 DEVICE

This section deals with the initial networking setup of your new *T/Guard 408XT* instrument.

Your new *T/Guard 408* comes calibrated and ready to use. Plug in the Ethernet cable (which is yellow in the photo below) decisively in order to hear an audible click. Next, connect the provided power cable. The unit does not have a power switch button, and should boot immediately. The display should look like the image below in less than 30 seconds:




Out of the box, the device is configured to use static IP address 10.0.0.4, Netmask 255.255.255.0 and Gateway 10.0.0.1 so that you can connect your *T/Guard 408* directly to a computer, either a PC or a Mac, using the Ethernet link. This approach is the Neoptix

factory default, using a “private” network arrangement. You can also quickly set up the device to obtain a dynamic IP from a DHCP server on an existing network. This will be described after the next section.

8.3 FIRST APPROACH: SETTING UP A PRIVATE NETWORK (STATIC IP)

The “private” network approach with static IP 10.0.0.4 is illustrated here:




To keep your workstation connected to your organization’s network, you will need an additional Ethernet interface / adapter, such as a USB to Ethernet device (this can be purchased for a nominal fee at any computer store; we recommend the Ulinx adapter from www.bb-electronics.com). This has the advantage of keeping the *T/Guard 408* isolated from all outside networks and thus will provide the best security scheme.

This section includes some information on how to set the network parameter, using a static IP address (private network). Here, you will connect your PC directly to the *T/Guard 408* using a “crossover” Ethernet cable⁴, as illustrated in the figure above.

We will assume here that the IP address of your computer Ethernet interface will be set to 10.0.0.3⁵ (see instructions below) and the IP address of the *T/Guard 408* will be 10.0.0.4.

You can verify the network IP address on the *T/Guard 408* display by pressing the leftmost button until you reach the Ethernet menu (“*EtHE*”), then click the second OK button: this will display 10.0.0.4 alternately blinking with “Address”. The blinking will time out after about 30 seconds and the unit will return to the previous temperature display.


Next, you need to make sure your PC computer is also set to work with a static IP address, which should be 10.0.0.3. For this, you need to open the *Windows Local Area Connection* window, as shown here:




⁴ If using a recent (less than ~5 years) PC, a crossover cable may not be required, as the newer PCs have Ethernet interfaces that can auto-detect Ethernet signal flow direction.

⁵ For more information regarding IP address selection, please visit http://en.wikipedia.org/wiki/IP_address.

And then open the *Properties* window. Select “*Internet Protocol Version 4*” and click the *Properties* button; you should get the following window (left). Select the “*Use the following IP address*” button, and enter the information as shown in the figure on the right, below:



Alternatively, you can also enter a fixed IP address using the “*Alternate Configuration*” tab shown in the above left picture. By doing so, it would be easier to switch back and forth between a DHCP enabled configuration (such as would be required in an office environment) and a fixed IP configuration (such as would be required to directly interface with a *T/Guard 408* system). This is illustrated here:



Exit all open configuration windows by clicking the *OK* buttons.


If you have problems connecting to the Ethernet, or to understand the parameters in the red box above, you should contact your Local Network Administrator for help.

Alternatively, you can also work with a dynamic IP address (DHCP server), even if you are connected directly to your *T/Guard 408*; this can be done by installing a shareware in your PC, which would act as a private DHCP server. Neoptix has successfully used the “*DHCP Server for Windows*” software, which can be downloaded from <http://www.dhcpserver.de/dhcpserver.htm>⁶. The readme.txt file gives instructions on how to use this very useful program (in particular how to set a range of searchable IP addresses, with the *IPPOOL_1* variable).

⁶ Do not run as a service unless you want to use this configuration as a permanent installation.

8.4 WORKING WITH THE INTERNET BROWSER (FIXED IP ADDRESS)

Start your compatible⁷ web browser⁸. In the address bar, enter “10.0.0.4”⁹. The first page you will see is the login page, as follows:



Help suggestion: You may have to reboot your PC computer so a recently connected 408XT instrument will be “detected” your Ethernet connection; So, if you believe all your settings are correct, and your PC do not “see” your 408XT instrument, it is suggested to reboot your computer.

Using the web interface, you will be able to refine your static network settings if you wish.

8.5 SECOND APPROACH: SETTING UP DYNAMIC ADDRESS (DHCP SERVER)

This assumes you are familiar with networking computers, and that you have a DHCP server (such as a router) already running on the network you want to connect the T/Guard 408 to.

Here are the quick steps:

- On the display of the T/Guard 408, click the leftmost MENU button until you reach the Ethernet menu (“EtHE”);



- Click the second OK button once, the blinking “Address” submenu will be displayed along with the current IP address:


⁷ The following browsers are supported:

- Mozilla Firefox version 4.0 and above (recommended).
- Microsoft Internet Explorer version 7 and above.
 - Note on Explorer version 10: Some functionalities (e.g. file upload) will only work when using firmware version 3.92 and above. Contact Neoptix if you need to upgrade your instrument.
- Google Chrome version 16 and above.
- Apple Safari 5 and above.

⁸ A note concerning Microsoft Internet Explorer:

Recent versions of Internet Explorer (versions 9 and 10 in particular) may display some pages in a distorted way; this is due to compatibility issues in Explorer. This can be solved through a setting in Explorer, using “Compatibility view settings”.

⁹ The various screen pictures that are included in this guide may show different IP addresses in the address bar; this inconsistency is due to the fact that these screenshots have been done at different moments using different settings.




- Click either the third or fourth UP/DOWN button once, and the "IP" submenu will be displayed blinking along with the current "STATIC" configuration;



- Click the second OK button once, and the "STATIC" submenu will begin blinking instead of "IP". Next click on either the third or fourth UP/DOWN button once, the "IP" submenu will be displayed along with a blinking "DHCP":




- Click the second OK button once, the message "Rebooting wait" will appear and the device will reboot:



- As it reboots, the T/Guard 408 will communicate with the DHCP server, and obtain an IP address. You will be able to view this address by pressing the leftmost MENU button until you reach the Ethernet menu ("EtHE"), then click the second OK button twice. For example, on our own internal network, the device obtained the IP address "10.75.6.59" as illustrated here:



- Copy down the displayed IP address into the address bar of the web browser on your workstation and click the Go button in the browser: this will display the red Login page of the T/Guard 408. For example, on Neoptix own internal network:



8.6 THE T/GUARD 408XT WEB APPLICATION

8.6.1 NOTE CONCERNING THE WEB BROWSER CACHE

All web browsers are not made the same and do not behave identically by default.

Although every effort has been made in the T/Guard 408 web application to prevent your web browser from storing (also called “caching”) information which can quickly become outdated or confusing by sending precise directives to your browser, certain modern web browsers simply ignore or override these directives in favor of user-defined settings by default.

In addition, the behavior of a web browser will vary from one version to the next because of divergent design and security considerations, or contradictory interpretations of new technology specifications.

Caching can lead to unpredictable results, especially if working with more than one T/Guard 408 devices on your network at the same time, different only in MAC addresses and IP addresses.

For this reason, it is important for you to set your web browser from preventing caching. There is a “wikihow” web site which explains how to do this for all major browsers at:

<http://www.wikihow.com/Clear-Your-Browser%27s-Cache>

Sometimes because of aggressive caching, even refreshing a web page does not work. Here are the steps to prevent caching on the Windows 7 English versions of Firefox, Internet Explorer and Chrome.


For Internet Explorer 8

Overall, Internet Explorer is a browser that is eager to cache data by default.

1. Once your browser is open, click the Tools menu. Or, optionally you may simply press Ctrl+Shift+Delete to open the Delete Browsing History window (and skip step 2);
2. Click on Delete Browsing History...
3. Select Temporary Internet Files.
4. Click the Delete button near the bottom of the window to delete your temporary files (i.e. clear your cache).
5. Click the Tools menu and go to Internet Options and to the Advanced tab. Click to check the box next to the Empty Temporary Internet Files folder when browser is closed option (in the section labeled Security). Click OK. This will delete everything except cookies. Note: IE8 has a "feature" which retains some cookies even after you clear your cache if you do not UNCHECK the "Preserve Favorites Website Data.", so uncheck this as well.

For Firefox 13 and above


1. Go to menu Tools > Options > Advanced > Network tab




2. In the “Cached Web Content” section, click the “Clear now” button ;
3. Check the “Override automatic cache management” check box;
4. Set it to 0 MB of space.

For Chrome 21 and above


1. Go to menu Tools > Clear browsing data
2. Select “Empty the cache”, as shown here:





8.6.2 LOGIN PAGE



Selecting a different language from the dropdown list at upper right will display the web site in a different language (see note 1). Currently twelve languages are available (see note 2):




Notes:

- 1- Please note that the language selection is not stored in the 408 instrument; instead it always reverts to English when a new web session is open by a user. For example, if 2 users are concurrently connected to the same 408 instrument, each user can select the language of his or her choice.
- 2- If you get characters such as follows: , this indicates that your browser is mixed up while dealing with different character encoding. With Internet Explorer, this problem can usually be corrected by right clicking anywhere in your web page, then select "Encoding", and then "Unicode (UTF-8)"; with Firefox, select "Firefox" (lower top corner), then "Web Developer", then "Character Encoding" and then "Unicode (UTF-8)"; with Google Chrome, select , then "Tools", then "Encoding" and then "Unicode (UTF-8)". This should solve this problem.

It is required to log on to view data remotely. Out of the factory, two users are programmed by default:

- 1- Administrator level (user name "neoptix", password "pass")
- 2- Viewer level (user name "guest", password "guest")

It is very important to change the admin user name and password on first use; you will be reminded to do so every time you log in; however, there is no obligation to change any user name or password.



The guest user can be deleted outright, if you wish.

The regular user programmed by default into the device cannot be deleted and cannot be modified into a guest account.

The T/Guard 408 does not currently support single sign-on networking (through LDAP) or digital encryption certificates.

The word "Alarms" will flash in all windows when any unacknowledged alarms are active. You can clear this by either acknowledging any pending alarms, or by disabling this feature in the "Alarm management" window (see Section 8.7.26).

8.6.3 CONFIGURABLE COLORED DOTS IN THE WEB PAGE HEADERS




When there are several *T/Guard 408XT* devices on your network and they each need to be configured, it could get rather confusing because all the web applications look identical.

To help differentiate between devices, configurable colored dots were added to the web application. To modify the color of the dots on all the pages of one device, a user with administrative privileges simply clicks on one of the dots and a color picker control appears:



Next, select a new color by clicking on it in the control. To finalize a selection and dismiss the control, click outside the color picker. You will be prompted to confirm the selection:



If you choose to keep the new color, it will become permanent even after the device reboots.



This way, each *T/Guard 408XT* on your network can be “color coded”, conveniently preventing all too human mistakes.

A guest user cannot modify the dot colors.

A reset does not affect the dot color either, once again to prevent confusion.

8.7 WEB PAGES FOR AN ADMINISTRATOR USER


8.7.1 T/GUARD 408XT HOME PAGE

This is the start page for the web application.

The screen shots shown below have been done with an 8-channel system. The temperatures are updated live on the web page every few seconds.

There is nothing to configure or modify here.

On this web page, if a channels indicates “---.-”, it means it has no sensors attached or the probe is broken. A channel indicating a blank means it is disabled (none such displayed below, channel 8). The same scheme is used on the LED display menu.



Displayed temperature unit (C or F) can of course be modified, on the *Global Probe Parameter Setting* web page, see Section 8.7.29.

The number of displayed channels will change according to the number of optical channels present in the actual instrument being interrogated now, e.g., a 16 channel instrument will display 16 temperature values in a unique home window.

Alarms indicate whether a relay condition that was flagged as an alarm was triggered. The “Alarms” section on this web page is refreshed every 10 seconds. Once the alarms are acknowledged, the alarm warning that appears in the window header will be erased.


If real time graphics are required, the use of OptiLink-II is highly recommended. See next chapter for more information.

Current global temperatures (highest and lowest) are also displayed in this window (these are *not* cumulated values).

Internal temperature is also available¹⁰.

8.7.2 STATUS PAGE (DEFAULT VIEW)

This page has three different views. The extra views provide some additional network configuration details and statistics, which are nice to have in certain rare situations. The view pictured below is shown by default.



¹⁰ Internal temperature will take a few minutes to stabilize after the power is applied to the 408.

8.7.3 STATUS PAGE (RAW ETHERNET STATS VIEW)

This web page will provide network details in a format very familiar to most computer network administrators.

System Information

System name: Qualitrol TGuard 408
 Substation name: Neoptix
 Location name: Frank-Carrel
 Geographic coordinates: 46.797|-71.258
 Firmware version: 3.69
 Web server version: 1.4.28
 System time: 2013-04-06 08:21:47
 Up time: 0 day, 18 hours, 25 minutes, 26 seconds
 Last modified: 2013-03-01

Number of temperature channels: 8
 Number of relays: 8
 Display type: LEDs, Hardware revision version 1
 Disk space available for logs: 61% used (399.7M/254.3M)

Interfaces

Ethernet settings and statistics

eth0 Link encap:Ethernet HWaddr 00:08:EE:03:DD:97
 inet addr:192.168.1.13 Bcast:192.168.1.255 Mask:255.255.255.0
 UP BROADCAST RUNNING MULTICAST MTU:1500 Metric:1
 RX packets:16534 errors:0 dropped:0 overruns:0 frame:0
 TX packets:19713 errors:0 dropped:0 overruns:0 carrier:0
 collisions:0 txqueuelen:1000 RX bytes:2470148 (2.3 MiB) TX bytes:15871989 (15.1 MiB)

lo Link encap:Local Loopback
 inet addr:127.0.0.1 Mask:255.0.0.0
 UP LOOPBACK RUNNING MTU:16436 Metric:1
 RX packets:844 errors:0 dropped:0 overruns:0 frame:0
 TX packets:844 errors:0 dropped:0 overruns:0 carrier:0
 collisions:0 txqueuelen:0 RX bytes:73080 (71.3 KiB) TX bytes:73080 (71.3 KiB)

[click here to view formatted Ethernet stats \(takes about 10 seconds\)](#)

Serial link

Protocol: Neoptix ASCII protocol
 Type: RS485-4w

8.7.4 STATUS PAGE (FORMATTED ETHERNET STATISTICS VIEW)

This web page provides the same basic information as the previous, in a user friendly way. Because information is heavily processed, filtered and re-assembled, this view takes a few extra seconds to load.

System Information

System name: Qualitrol TGuard 408
 Substation name: Neoptix
 Location name: Frank-Carrel
 Geographic coordinates: 46.797|-71.258
 Firmware version: 3.69
 Web server version: 1.4.28
 System time: 2013-04-30 04:41:25
 Up time: 4 days, 23 hours, 27 minutes, 6 seconds
 Last modified: 2013-05-01

Number of temperature channels: 8
 Number of relays: 8
 Display type: LEDs, Hardware revision version 1
 Disk space available for logs: 8% used (52.1M/601.9M)

Interfaces

Ethernet

IP address: 192.168.1.13
 Subnet mask: 255.255.255.0
 MAC address: 00:08:EE:03:DD:97

	Total	Dropped	Errors
Received packets:	75228	0	0
Sent packets:	75228	0	0

[click here to view raw Ethernet stats \("ifconfig" view\)](#)

Serial link

Type: RS485-4w
 Protocol: Neoptix ASCII protocol

8.7.5 TIME SETUP PAGE (AND NTP SERVERS)

The date and time are used in temperature logs and with protocols such as IEC 61850.


On this web page, you can correct the date and time to your own local time, and these settings are persistent after a reboot or after a lengthy power down.

The *T/Guard 408XT* supports NTP time synchronization, to comply with protocols such as IEC 61850. This synchronization requires that this *T/Guard 408XT* has access to the Internet. 2 NTP servers are suggested by default (see image below); these 2 are considered as reliable NTP servers as available over the open Internet network. The first one is interrogated, and if no answer is received, the *408XT* will try to synchronize using the second server, and so forth. You can use your own NTP server if you so desire; in this case, adapt the IP addresses as required; up to 3 NTP servers can be suggested.

The main purpose of NTP servers is to insure that multiple instruments (e.g., multiple *T/Guard 408's*) are synchronized together.


The time zone adjustment is required only to display correctly the local time and date.

If no NTP server is to be used, then unclick the synchronization box; in this case, you will be able to adjust the local time and date to your likings.



8.7.6 LABELS AND INTERFACES PAGE

This web page provides you with a meaningful way of identifying your *T/Guard 408*, perhaps among many in your substation. The combination of system name, substation name, and location name information provides a friendly and practical identifier combination for the device.




Qualitrol has an optional mobile wireless device application for Apple iOS based devices. The “iApp” application allows remote monitoring of a *T/Guard 408XT* system. A well-formatted GPS latitude and longitude in the *Geographic coordinate’s* field will be used to display the device accurately on a street map, which might be useful for personnel on the road.

If your instrument includes the 100Base-FX option, you can switch between this protocol and 10/100Base-T here. You should save your change with the “Save button”; this change, as well as the “Enable DHCP” setting, would become effective *only* after a system reboot.

Please refer to the *Important Security Disclaimer* in Section 3 regarding internet security.


8.7.7 MANAGE SERIAL PORT PROTOCOLS

This page also allows you to properly configure your serial port (RS-485) either in half-duplex or full-duplex configuration; in either case, you must make sure that your external wiring matches your selection (half for 2 wires, full for 4 wires).



In the above window, we can see that all serial protocols have been licensed and have been launched at least once. A pointmap.txt file is generated dynamically by the DNP 3.0 server or the IEC 60870 server on first run and the download links above will only be displayed if the pointmap.txt file actually exists. The DNP 3.0 protocol is available in either 16 or 32 bit; you should select 32 bit, unless your SCADA system supports only 16 bit.

If a protocol has not been licensed, it will not be available and a hyperlink will be provided leading to the registration web page where you should enter the license code provided by Qualitrol Sales.



Once again, it is useful to point out that the half duplex setting will work properly when matched with a corresponding hardware configuration (see Section 6.2). By default the setting is full duplex.

8.7.7.1 Configuring serial protocols

When using the serial protocols, one needs to pay attention to parity and stop-bit settings. The following restrictions are applicable:


Modbus: Although this protocol has some restrictions, the Neoptix implementation of the serial Modbus product accepts any combination of stop bits (1 or 2) and of parity bit (none, even or odd).

DNP3: The only combination supported is parity None and 1 stop bit.

IEC 60870-5-101: The only combination supported is parity Even and 1 stop bit.

For all serial protocols, the baud rate is adjustable to 9600, 19200, 38400, 57600 or 115200.


8.7.8 MANAGE ETHERNET SMART-GRID PROTOCOLS




The above web page screen capture indicates a *T/Guard 408* where all the Ethernet SMART GRID protocols have been licensed. Out of these, only the Modbus over Ethernet protocol comes standard with the *408XT* model, other protocols need additional licensing. Please refer to Qualitrol Sales for more information.

Suggestion: To preserve processor power, it is better to enable only the protocol(s) that you may eventually use. If they are not used, it is better to keep them inactive.

Some protocols, such as IEC 61850, require a unique device name which is in fact a combination of three fields (short name, substation and location). If you have more than one *T/Guard 408* on your network, each should have different identifying labels. To modify these, click on the topmost hyperlink on the web page illustrated above, and this will lead you to the appropriate web form:




Each protocol, once enabled, has a matching configuration web page available.




More than one protocol can be enabled at the same time, as illustrated above, however, if you are not using a given protocol then you should not enable it as it will engage system resources unnecessarily and impact overall performance.

8.7.9 CONFIGURATION WEB PAGE FOR THE IEC 61850 PROTOCOL



The IEC 61850 protocol by default does not require a password, and allows any client to connect to it. It is possible to enforce the exchange of passwords by checking the *Security Mode* checkbox in the web page illustrated above.

This will allow the setting of three different passwords:




Saving passwords here will force a client to provide one of the three passwords in order to connect.

There is currently no difference in functionality offered by the protocol depending on the level of security, i.e. each password will have access to exactly the same information.

The “*.icd file download” link can be used to download the IEC 61850 ICD file. This hyperlink will appear only if the IEC 61850 protocol has started. By default, this file is called qgateway.icd.

For more information about the ICD file, please refer to Neoptix document # g1030rxx, Protocol Reference User Guide.

8.7.10 CONFIGURATION WEB PAGE FOR THE DNP 3.0 PROTOCOL




More than one client can communicate with DNP 3.0 LAN, but they must be separately configured and must each have a unique master station / secondary station combination. For example, the second and third clients above could have the same master station address of 65500 but with a secondary station (slave) address of 2 and 3 respectively.

Do not configure additional clients if they are not required as this will consume system resources unnecessarily and impact on overall performance.

Note that you can download the pointmap.txt from this web page. Currently at the time of this writing, the pointmap.txt for the DNP 3.0 serial and DNP 3.0 LAN protocols are identical; however, this may change in future firmware revisions. Note: this file should be read using WordPad, not Notepad.

DNP3 is offered in 16 or 32 bit variances. 32 bit is preferred, but if you SCADA system does not support 32 bit, then you should select 16 bit. Changing this parameter will force a processor rebooting step.


8.7.11 CONFIGURATION WEB PAGE FOR THE IEC 60870-5-104 PROTOCOL



The device address id can be modified here.

You can download the pointmap.txt from this web page. Currently at the time of this writing, the pointmap.txt for the 60870-5-101 serial and 60870-5-104 Ethernet protocols are identical; however, this may change in future firmware revisions. Note: this file should be read using WordPad, not Notepad.


8.7.12 CONFIGURATION WEB PAGE FOR THE MODBUS OVER ETHERNET PROTOCOL



The device address id can be modified here. This id must be between 1 and 247 (0 is not valid, and values from 248 to 255 are tolerated although as per the Modbus protocol they are illegal). It is suggested to always use id=1, even when multiple 408XT units are networked together, as then the device IP address is in practice the real id differentiator.

The pointmap.txt for Modbus LAN (Modbus over Ethernet) can be downloaded here. Note: this file should be read using WordPad, not Notepad.


8.7.13 FILE TRANSFER



On this web page, it is possible to download (transferring a file to your PC):


- The locally stored PDF user guides (408 and smart protocols)
- The user, relay condition and relay name custom configurations (.cfg files)
 - These files are useful to reconfigure a similar instrument exactly as this one. Do not edit these files!
- The status file (includes most general parameters); this file is very useful to view an overall picture of a 408, in text form. This is a very useful file to email to Neoptix, to help diagnose problems
- The TransLife log file. This is also a .cfg file; it can be downloaded from this instrument and then uploaded to a new instrument. It is not strictly speaking a configuration but rather a log file that includes the accumulated TransLife life use from this instrument; so, uploading this file to a new instrument will allow this new instrument to continue evaluating the loss of life for a given transformer.

This figure shows the complete list of files that can be downloaded:




It is also possible to upload (transferring a file to the 408XT):

- Web server file updates (other than .php extension files, which can only be updated via a firmware update); this type of upload must only be done under the supervision of a Neoptix support engineer
- A visual jpeg file can also be uploaded to replace the standard image supplied with your instrument. This is the image that appears in the web page described in section 8.7.30
- The user, relay condition and relay name custom configurations (.cfg) to duplicate settings from another unit (previously downloaded).



Web server files should be uploaded only under the supervision of a Neoptix support engineer. This type of upload can be to perform minor firmware upgrades. Generally speaking, a full upgrade (see below) would be preferable to a partial upgrade.




The upgrade file would normally be sent to you by a Neoptix engineer; the file is normally sent in zip format; you will need to unzip it to a local drive before proceeding with the upgrade.

It is also possible to reset the unit to factory defaults, or to restart the unit. This can be done using the “Reset” button found on the same web page.

8.7.14 USER MANAGEMENT PAGE

This web page lists current users and provides an “Add New User” button. A maximum of 10 different users can be configured on the system.


To modify the role for, and/or delete or rename a user login/password, click on the hyperlink. Please note that the factory-provided default user cannot be deleted, nor can the user role for this account be changed.



8.7.15 ADD NEW USER PAGE

This page will be available only as long as there are ten or less user accounts, as only a maximum of 10 is supported. A given user name can be used only once.


This window is self-explaining.



8.7.16 MODIFY MAIN USER ROLE PAGE


Both the password and the login name can be changed.

Once again, please remember that the “admin user” is the only account which cannot be deleted, although the original factory login and password can be restored, by following this procedure: There is a reset button sequence available on the local keypad of the 408XT to restore the default web user: simply hold down the left two buttons (*MENU* and *OK*) simultaneously for 5 seconds and the message “web user reset” will appear for a few seconds. You will then be able to log in using the original user name (*neoptix*) and password (*pass*) provided by default with the device.




8.7.17 MODIFY / DELETE OTHER USER PAGE

A user other than the main regular one can be deleted, and his login, password or role can be changed.




8.7.18 LOG DOWNLOAD (AND DELETE) PAGE

Available temperature logs can be downloaded by clicking the hyperlink link.




Temperature logs are in fact tab-separated .csv text files renamed to a .tem file extension. The .tem file extension name is a convenience allowing users to associate this file type to Microsoft Excel on their workstation. This convenience has been extended in the T/Guard 408XT to associate in the web server the .tem file extension with Microsoft Excel. By clicking the link on this web page, you will be able to either save the file to local disk, or to open the downloaded log directly in Microsoft Excel.

Here is an example screenshot of the Firefox web browser message:



If you use another program than Microsoft Excel, it is recommended you save the file to disk first. If you get the following message:



Click "yes" to continue. Excel should then come up with a file that would look like this:

The screenshot shows Microsoft Excel with a table of temperature data. The table has columns for Date, Time, POSIX.time, Channel #, and eight temperature channels (HV2 through #8). The data is as follows:

1	Qualitrol T/Log File	Temperature Data (degrees C)									
2	(serial #v5-08-11)										
3	Channel Name:	1:~LV,~ph 2:~HV2	3:~HV~ph	Channel4	Channel5	Channel6	Channel7	Channel8			
4	Date	Time	POSIX.time	Channel #	Channel #	Channel #	Channel #	Channel #	Channel #		
5	3/3/2013	17:24:16	1362331456	25.7	35.8	28.3	28.2	29.5	28.2	27.6	27.6
6	3/3/2013	17:24:53	1362331493	25.7	35.7	28.4	28.2	29.5	28.2	27.6	27.5
7	3/3/2013	17:25:53	1362331553	25.7	35.7	28.1	28.2	29.5	28.1	27.5	27.3
8	3/3/2013	17:26:53	1362331613	25.8	35.7	28.3	28.2	29.5	28.2	27.5	27.3
9	3/3/2013	17:27:53	1362331673	25.7	35.7	28.2	28.1	29.5	28.2	27.6	27.3
10	3/3/2013	17:28:53	1362331733	25.7	35.7	28.3	28.1	29.5	28.1	27.5	27.4

Column C, POSIX.time, gives the Unix time, in seconds since January 1st 1970. This could be useful to simplify the generation of graphics in Excel. This time is based on the UTC time, not the local time; however, columns A and B (Date and Time) are in local time.

New log files are started when 60000 lines are reached (to be backward compatible with some older versions of Microsoft Excel), or if the temperature unit is changed, or if logging is enabled and the current log file is deleted.

Notes on file naming convention:

- The current log file is always named temperatures.tem, where the extension tem stands for temperature
- Archived files are named with a prefix that corresponds to the date and time at the time it was archived.


Hint: to easily make a graphic in Excel with a simple X axis that represents time, one could simply subtract the Posix time at time “0” of the X axis; this would give a graphic with the X axis in seconds (which in turn could be divided by 60 to get the axis in minutes, and so forth).

8.7.19 LOG VIEWER PAGE

To navigate in this page:

- Click on the link for the available log file you wish to view in the left menu
- Navigate from page to page with the arrow buttons at the bottom.

Each page presents up to 100 rows of data. Don’t forget that these logs can be downloaded through the “Log download” page and opened as an Excel spreadsheet (it’s much faster that way).




Numbers equal to -999 are error codes; for example -999.66 indicates that no sensor was detected for that channel. This convention is used to assure compatibility with Excel.

8.7.20 LOG SETTING PAGE

Here you can enable or disable logging (effective immediately, no reboot of the device required).

You can also change the logging rate from 1 second to 1 hour. The normal logging rate is once every 10 minutes. Please remember that a logging rate under one minute is considered excessive and should rarely be used. For this reason, if the device reboots with a currently set logging rate of less than one minute, it is automatically reset to a rate of one log saved per minute.



A modified logging rate is also applied immediately.


8.7.21 RELAY CONDITION OVERVIEW PAGE

This page lists a summary of all 128 relay conditions in one convenient web page. Refer to the next sections for instructions on how to set these conditions. This page is read only. One can get the same information by downloading the status page; see Section 8.7.13.

Condition number	Status	Condition name	Condition type	Temperature set point (°C)	Hysteresis (°C)	Optical channel number	Associated relay number	Event log	Alarm condition
1	Enabled	Alarm 1	Channel greater than set point	120.0	5.0	3	2	Enabled	Disabled
2	Enabled	Alarm 2	Channel greater than set point	150.0	5.0	9	2	Enabled	Enabled
3	Enabled	Alarm 3	Channel greater than set point	105.0	5.0	9	3	Enabled	Enabled
4	Enabled	Trip	Channel greater than set point	130.0	5.0	9	4	Enabled	Enabled
5	Disabled	Cond.#5	None	200.0	5.0	1	1	Disabled	Disabled

8.7.22 RELAY SETUP PAGE

As a first step, it might be a good idea to “name” the relays according to their logical function; this can be done selecting in the navigation links on the left, “Relay conditions” > “Relay setting”, as shown here:




This window gives you also the opportunity to define any relay as being in “Fail Safe” mode, which will inverse the physical logic assigned to this relay. Please note that after a power up sequence, it will take about 20 to 30 seconds before the fail safe mode is enforced; for this reason, all relays that are set in fail safe mode, should be implemented using a “time delay relay” (delay on operate), to avoid problems at system power up.

Then you should select “Relay conditions” > “Condition setting”; experimenting with this window, shown below, would be a good way to learn about relay condition setting.


Hint: To test relay operation, you can simply change this relay failsafe mode repetitively; do not forget to save to activate the new status.

8.7.23 RELAY CONDITION SETTING PAGE

This page allows setting and modifying relay conditions. Up to 128 conditions are allowed.



Of particular interest is the “Condition type” setting options, as illustrated here:



The description of these conditions is given here:

- 1- Channel has no signal. Useful for flagging a no-signal optical channel (probe broken, extension cable disconnected, etc.)
- 2- Channel lower than threshold. Relay will be activated if the temperature on the selected “Channel number” is below the “Temperature set point” value
- 3- Channel greater than threshold. Relay will be activated if the temperature on the selected “Channel number” is higher than the “Temperature set point” value.

These condition settings offer ultimate flexibility for controlling how your relays will operate. All other parameters are self-descriptive. A total of 128 conditions can be created. Conditions cannot be deleted; however, they can be disabled or overwritten with new information.

When selecting the optical channel that would be associated to a relay, you are also given the possibility to select “Highest” or “Lowest”; this can save entering many condition entries by allowing a common situation where any enabled channel higher than the specified threshold will activate the specified relay (select “Highest” in this case instead of a specific optical channel number).

Note that “Highest” is a selection you can make in the “Optical channel number” dropdown list:

Channel number:	1
Associated relay number:	<ul style="list-style-type: none"> 1 2 3 4 5 6 7 8 Highest Lowest

When a relay condition is triggered, this constitutes an “event”. An event can be either logged or not for a given condition. Also, an event can also be defined as an alarm.

Some comments on “Event logging” options: Events are defined as an operational condition that might be useful to log. Not all relay operations should be labeled as events; indeed, for example if a relay is controlling a fan cooling bank, this is probably not an event, so its logging would probably be disabled, and it should not create an alarm situation. On another hand, if you have a condition whereby the temperature on any probes is higher than 120°C, and it is required to trip the transformer, this is clearly an event that should be logged and create an alarm situation when it occurs. Remember that any alarm must be acknowledged on the T/Guard-408 local keypad; one would normally not want thousands of those!

Each event that has created a logged alarm condition will have 2 entries in the event log file: the first entry will occur when the alarm condition is created and the second entry will be when this condition ceases to exist.

Any non-acknowledged alarms are automatically acknowledged when the system reboots. However, all alarms already logged in the event log file are kept permanently, unless this file is intentionally deleted.

Alarms are special in several ways:

- They are always logged;
- The last 10 alarms are displayed on the “T/Guard 408 Home” start web page and on the “Manage Alarms” web page, in order of the most recent to oldest;
- On the “T/Guard 408 Home” start web page, the “Alarms” section is refreshed every 10 seconds;
- Alarms can be dismissed on the “Manage Alarms” web page by clicking the “Acknowledge to clear alarms” button. On the *T/Guard 408* front panel display, the LED marked “Alarm OK to Clear” will light up if there is at least one alarm (please note that only *T/Guard 408* units marked with this indication will provide this last functionality);
- Alarms can be dismissed from the display by simply clicking the OK button while temperatures are being displayed (please note that only *T/Guard 408* units marked with this indication will provide this last functionality).

Although it is possible to copy relay condition name settings from one *T/Guard 408* device to another using the File Transfer web page, please note that relay condition names are a web-only convenience and exist only on the *408XT* model. For this reason, they are stored differently and require a separate file download and upload, i.e. the item “*T/Guard 408 Relay Condition Name List (.cfg)*”.

8.7.24 RELAY CONDITION EXAMPLE

This example assumes that 4 probes are installed in the transformer. In this example, a probe is used to control the fan cooling (this would normally be the probe that would have exhibited the highest temperature readings during the heat run test).

Probe locations (4):

- 1- Winding, high voltage (W-HV); connected to channel # 1 on *T/Guard 408*
- 2- Winding, low voltage (W-LV); connected to channel # 2 on *T/Guard 408*
- 3- Winding, tertiary (W-TV); connected to channel # 3 on *T/Guard 408*
- 4- Winding, low voltage (W-LV) (could be a spare to probe # 2); connected to channel # 4 on *T/Guard 408*.

Relay definitions (6):

- 1- Relay # 1, for cooling fans, bank # 1. Should be activated when probe # 1 reaches +70°C
- 2- Relay # 2, for cooling fans, bank # 2. Should be activated when probe # 1 reaches +80°C
- 3- Relay # 3, alarm, level # 1. Should be activated when probe # 2 reaches +95°C
- 4- Relay # 4, alarm, level # 2. Should be activated when probe # 2 reaches +105°C
- 5- Relay # 5, alarm, level # 3. Should be activated when probe # 3 reaches +110°C
- 6- Relay # 6, transformer trip. Should be activated when any of the 4 probes reach(es) +120°C.

Assuming the above conditions, the following parameters would need to be set, either via the web browser or by relay condition files (with *OptiLink-II*).

Cond. #	Cond. Name	Cond. Type	Set Point	Hyst.	Ch #	Assoc. Relay#
1	Bank1	Channel greater than threshold	70	5	1	1
2	Bank2	Channel greater than threshold	80	5	1	2
3	Alarm1	Channel greater than threshold	95	5	2	3
4	Alarm2	Channel greater than threshold	105	5	2	4
5	Alarm3	Channel greater than threshold	110	5	3	5
6	Tfr-Trip	Channel greater than threshold	120	5	Highest	6

8.7.25 EVENT LOGGING DOWNLOAD PAGE




On this web page, an event log can be downloaded by clicking on the hyperlink.

Just like a temperature log, an event log is limited to 65,000 lines. If it exceeds that, it is archived. Archives will also be displayed here and can be downloaded. Event files are tab delimited .csv files, and can be directly read by Excel.

A guest user cannot delete event logs.

8.7.26 ALARM MANAGEMENT PAGE



On this web page, alarms can be acknowledged. Please note only the last 10 most recent unacknowledged alarms are displayed on this page. Once acknowledged, the alarm warning that appears in the header is also cleared.

A guest user cannot acknowledge alarms.

8.7.27 OPTICAL CHANNEL PARAMETER OVERVIEW PAGE

This page lists a summary of all probe parameters, as programmed in the next steps (see next sections); in one convenient web page. This page is read only.

QUALITROL
Defining Reliability

English Help Logout

Administrative user

System

Temperature logging

Relay conditions

Optical channel setting

- Channel parameter overview
- Channel parameter setting
- Global parameter setting
- Visual
- TransLife™
- TransLife™ setting


Temperature channel parameter setting overview

Channel	Status	Channel name	Temperature offset (°C)	AnalogOut zero setting	AnalogOut span setting	Power % (wtune on)	Temperature (°C)
1	Enabled	PhB_LV_90	0.0	0	160	100%	25.7
2	Enabled	Channel2	0.0	0	160	100%	25.3
3	Enabled	Channel3	0.0	-100	400	100%	26.6
4	Enabled	Channel4	0.0	-100	400	100%	26.2
5	Enabled	Channel5	0.0	-100	400	88%	26.1
6	Enabled	Channel6	0.0	-100	400	100%	25.8
7	Enabled	Channel7	0.0	-100	400	100%	26.4
8	Enabled	Channel8	0.0	-100	400	100%	25.3


8.7.28 TEMPERATURE CHANNEL SETTING PAGE


This web page contains sensor information for one sensor at a time.

You can adjust here also the two analog output parameters, zero and span. An offset can also be entered; if you use an offset, this should be done at your own risk, as this will alter the instrument calibration. An offset greater than +200 or -200 is not permanently kept. Channel names can have up to 19 characters; a good strategy is to use the probe position as its name.



8.7.29 GLOBAL PROBE PARAMETER SETTING PAGE



- Temperature unit, in °C or °F.
- Sensitivity Optimization: It is recommended to keep this setting to “on”. When on, the system will optimize the reading of the probes, at the cost of being slower, so weaker probes can be successfully read. It is an automatic gain control, or “AGC”.
- Allow Measurement Dropouts: Could be useful for weak probes. A value of 5 is recommended.
- Analog Out Error Mode: 3 options are available: . This is used to define the output behavior of when the corresponding probe is not giving a valid temperature reading. “Toggle min-max” is the default value.
- 2nd calibration: You should select this option only when you are using Nortech Fibronic probes, or equivalent.
- Condition Cycle Time (seconds), from 1 to 300: This sets the frequency at which the relay condition setting is refreshed. A value of 10 to 20 is recommended.


8.7.30 VISUAL TEMPERATURE PAGE

It is helpful to be able to remember what part of a transformer a certain channel probe is connected to without having to physically go to the site and inspect the wiring set up. This web page allows you to do this at a glance.

You can graphically add a “label” displaying current temperature, channel name, and more to a diagram image representing a transformer.


One label per channel can be added to the diagram. Naturally, you should only add a label for a channel that has a sensor attached. Each label can be moved to the correct position by dragging them with your mouse.

If your transformer looks different, you can replace the background diagram image with your own by uploading a different image in the *System > File Transfer* web page, upper left *File Upload* section, select the item “*Visual background file (jpeg image, max 250 kb)*” in the dropdown list, click the “*Browse...*” button to select your substitute image, and finally, click the Upload button.




8.7.31 TRANS LIFE™ RESULT PAGE

This page contains the results of TransLife, based on the setup parameters from the next section. Please read the next section first, to understand what is shown in this TransLife result page. The TransLife data is calculated as per the accepted insulation life aging rate suggested by the IEEE and the IEC; the aging rate of insulation material is roughly given by this graphic:



Assuming we are using thermally upgraded paper, we can see that the nominal reference temperature for this paper is 110°C. We also know from IEC and IEEE studies that the aging rate doubles for approximately each increase of 6 to 7°C. The Neoptix calculation of insulation remaining life is based on these two assumptions. The following graphic that you can get by clicking on “*Click here to view cumulative graph*”, illustrates how the various temperature data is accumulated in 13 different bins, each bin width and position of the central bin can be adjusted in the next window (TransLife Setup).

This is the central bin, centered on 110 °C, in this example. Bin width is 6.5 °C.



TransLife™		
Present loss of life rate:	1.00	consumed minutes (40110)/operating minutes (40110)
Loss of life in the last hour:	1.00	consumed minutes (60)/operating minutes (60)
Loss of life in the last day:	1.00	consumed minutes (1149)/operating minutes (1149)
Total loss of life:	0 minute	(consumed minutes (40110) - operating minutes (40110))/60
Assumed transformer life:	20 years	(theoretical)
Remaining life left from assumed:	20.0 years	20 years - ((consumed minutes (40110) - operating minutes (40110))/(60 * 24 * 365))
Operating:	27.9 days	operating minutes (40110)/1440

Please note for the above only the highest temperature among those selected in the configuration is considered, calculated once per minute.

Currently selected unity temperature: 110 degrees C (1 HR Consumed = 1 HR Operating)


[Click here to view cumulative graph](#) [Stats cumulative](#)
[Click here to view last hour graph](#) [Stats last hour](#)
[Click here to view last day graph](#) [Stats last day](#)

[download transformer life.log \(file transfer page\)](#)

Currently, TransLife is only available on the 408XT instrument (it is not available on the 408).

8.7.32 TRANS LIFE™ SETUP PAGE

This page contains the parameters that are used to setup TransLife (previous section).



This window allows for setting the following parameters:

- Which optical channels will be taken into account when evaluating TransLife
- The assumed or estimated transformer life, in years (max of 100 years)
- The value, in degree C, of the doubling in age of the insulation material, typically 6 to 7 °C for Kraft and Aramid paper
- The nominal temperature, in degree C, where the aging rate is unity, typically +110°C for thermally upgraded Kraft paper
- For Aramid type paper (Nomex™), the unity temperature is approximately +185 °C.

This page offers you the opportunity to download the translife.log file which includes the accumulated minutes of use. Downloading this file could be useful so you can reload it in a new 408XT in case of replacement.

8.8 WEB PAGES FOR A GUEST USER

A « guest » cannot modify or delete anything. Here are the web pages he will be able to view. For more information about these pages, please refer to the previous Section 8.7.

8.8.1 LOGIN PAGE

Default username and password are “guest” and “guest” (no capital letters).



8.8.2 HOME PAGE

The screenshot shows the QUALITROL Home Page. The header includes the logo "QUALITROL Defining Reliability", a language dropdown set to "English", and "Help" and "Logout" buttons. A sidebar on the left lists navigation options: System (selected), T/Guard 408 Home, Status, Time setup, Labels and interfaces, Serial protocols, Ethernet protocols, Temperature logging, Relay conditions, and Optical channel setting. The main content area features a "Temperature Readings" section with four temperature displays: Channel1 (25.4°C), Channel2 (23.4°C), Channel3 (24.6°C), and Channel4 (25.3°C). Below this is an "Alarms" section stating "Currently no alarms." Two tables provide "System Information" and "Global temperature values".

System Information	
System name:	Qualitrol T/Guard
Substation name:	no substation defined
Location name:	no location defined
Geographic coordinates:	
Firmware version:	4.52
Web server version:	1.4.28
System time:	2014-11-11 17:54:27
Up time:	0 day, 1 hour, 26 minutes, 16 seconds
Last modified:	2014-11-07
Number of temperature channels:	4
Number of relays:	0
Display type:	7-segts LEDs, hardware revision version 13
Disk space available for logs:	584.93 MB

Global temperature values	
Highest Temperature:	25.4 °C (Channel 1)
Lowest Temperature:	23.4 °C (Channel 2)
Internal Temperature:	58 °C

8.8.3 STATUS PAGE

The screenshot shows the QUALITROL Status Page. The header and sidebar are identical to the Home Page. The main content area is divided into two sections: "System Information" and "Interfaces".

System Information	
System name:	Qualitrol T/Guard
Substation name:	no substation defined
Location name:	no location defined
Geographic coordinates:	
Firmware version:	4.52
Web server version:	1.4.28
System time:	2014-11-11 17:54:27
Up time:	0 day, 1 hour, 26 minutes, 16 seconds
Last modified:	2014-11-07
Number of temperature channels:	4
Number of relays:	0
Display type:	7-segts LEDs, hardware revision version 13
Disk space available for logs:	584.93 MB


Interfaces	
Ethernet	
IP address:	10.0.0.4
MAC address:	00:0C:06:78:4F:0C
click here to view raw ethernet state ("showif" view)	
click here to view formatted ethernet state (takes about 10 seconds)	
Serial protocols	
Type:	RS485-4w
Protocol:	Neoptix ASCII protocol

8.8.4 TIME SETUP PAGE


The screenshot shows the QUALITROL Time Setup Page. The header and sidebar are identical to the Home Page. The main content area features a "Current system date and time" section with the following details:

Current system date and time	
Local Time:	17:55 (hh:mm)
Local Date:	2014/11/11 (yyyy/mm/dd)
Local Time Zone:	America/Montreal


8.8.5 LABELS AND INTERFACES PAGE




8.8.6 SERIAL PROTOCOLS




8.8.7 ETHERNET PROTOCOLS




8.8.8 LOG DOWNLOAD PAGE



8.8.9 LOG VIEWER PAGE



8.8.10 LOG SETTING PAGE



8.8.11 RELAY CONDITION OVERVIEW



8.8.12 RELAY STATUS OVERVIEW PAGE




8.8.13 EVENT LOGGING DOWNLOAD PAGE




8.8.14 ALARM MANAGEMENT PAGE




8.8.15 TEMPERATURE CHANNEL OVERVIEW




8.8.16 GLOBAL PARAMETER PAGE



8.8.17 VISUAL TEMPERATURE PAGE



8.8.18 TRANS LIFE™ RESULTS



9 OPTILINK-II SOFTWARE DESCRIPTION (FOR THE 408)

OptiLink-II is particularly interesting for users of the non-Ethernet version of the 408, as it offers a friendlier procedure to load various parameters, such as relay and optical channel parameters that would otherwise require to be set by hand using the instrument 4-button keypad. For the 408XT version, this program is not recommended, except for the tool that can offer real time graphics; use the web server interface instead. Neoptix has recently started the development of this new software package, called OptiLink-II. The goals and purposes of this software packages are as follows:

- Display temperature information, for up to 16 channels per instrument, for a total of up to 4 instruments (maximum of 64 channels). This information can be seen in either digital or graphical forms. Data can be logged in a file, if desired.
- Acquired temperature information can be presented in graphical form, in both 2D and 3D format.
- Initialize and manage 408 relay and associated control parameters.
- Initialize and manage 408 optical channel and associated control parameters.
- Upload new 408 firmware (software upgrade).
- Download data and event logging files from the 408, and other files.

This software is still in development; contact Neoptix for the latest version (July 2015). Version 2.4 is described below.

Very important: The current version of OptiLink-II will work correctly with the 408 that has the firmware version 3.91 or later. If your 408 has an earlier version, contact Neoptix for instruction on how to do a firmware update with the latest version. However, if your firmware is version 3.51 or above, you can still run the latest version of OptiLink-II to perform a firmware update, as described in Section 9.9. If your firmware is older than version 3.50, contact Neoptix support for help.

OptiLink-II can simultaneously support up to 4 Neoptix T/Guard instruments, either through their serial COM ports or through their Ethernet ports (if available). Currently, this tool supports the T/Guard models T/Guard, Reflex, T/Guard-408, T/Guard-405, T/Guard+, Nomad, T/Guard-Link and T/Guard-Link; in summary, it is compatible with all instruments developed by Neoptix since 2005 (except the T/Guard2 gen1; the T/Guard2 gen2 will be supported in the future).

9.1 INSTALLATION AND INITIAL OPERATION


The Neoptix OptiLink-II tool is installed using a standard Microsoft Windows setup.exe package. Double-click on setup.exe to launch and accept the usual Windows Security warning to proceed.

OptiLink-II requires the Microsoft .NET Framework version 4.5. If this dependency is not present on the target computer, then it will be automatically installed first and a reboot will probably be required before resuming the installation.

On the *T/Guard 408*, make sure you have set the protocol to “Neoptix” (this is an easy thing to overlook). Make sure your serial port parameters are correct and that your cable matches your port duplex settings! Neoptix protocol serial settings are baud 9600, Parity None and Stop bits 1.

Warning: To reinstall the software, or install a new version, it is mandatory to first uninstall the older version. This must be done by using the “Program and Features”, found in Windows Control Panel.


After installing all the required software, a master application window will open as follows:



Or



All applications will require that you know which serial com port or which IP address is used to connect a Neoptix instrument¹¹ to OptiLink-II. For this purpose, each application has a port selector and a Connect button. The COM port selector will only list the currently available ports on your Windows installation (for Ethernet connection, you must enter the full IP address). This is the same list of available COM ports you would view in your Windows Hardware Device Manager:




Select the port connected to your *T/Guard 408* and click the “Connect” button.

Information confirms you have indeed communicated with the *T/Guard* and you will be provided with additional menu items (left pane). If connected through an IP address, only the Acquire Temperatures item is available.



9.2 ACQUIRE AND DISPLAY TEMPERATURE DATA


The “Acquire Temperatures” application will display up to 64 temperatures (16 temperatures for up to 4 instruments), as follows:




¹¹ The Acquire Temperature window allows connecting up to 4 compatible instruments to OptiLink-II simultaneously; all Neoptix instruments are compatible with OptiLink-II.

This window also includes a “Graph” button, which will open an additional window that will show a trend graphic for all previously selected channels (channel selection should be made prior to opening this second window). See section 9.2.2 for more information.


The main window also includes a feature whereby the user can save the data acquired since this window was open; this data file has the default extension .tem, and is a .CSV type file that can be directly read by Excel. Direct saving to an .xls file is also possible. Please note that data is being acquired ONLY when the “Acquire temperatures” window is active; however, the data will be saved only after the “Save log” button is clicked; this will open the following window:



If you have more than one instruments connected, then instead, this window will look like this, where more options are available to conditionally save specific channels:



Then, you will need to enter a file name and select if you want to save your data as a text .csv file, or as a genuine Excel file already acquired in kept in memory, and can be saved as any time using the menu item “Log” and then “Save log”, or by using the “Save Log” button found in the lower right corner of the main window. It is also possible to save data directly to Excel, if the file you select to save it is an .xls file, as illustrated here:



Then, all future data will be logged on your hard disk.

The latest version of OptiLink-II now supports data transfers to an Excel file; this transfer can be punctual or can proceed as temperature data is being acquired. Make sure you download the latest version from the Neoptix web site (www.neoptix.com).

Warning: this current implementation is weak in term of supporting user interaction with the Excel file during temperature acquisition; make sure you do not write or handle anything in the Excel application while an acquisition is active.

Information: This PC data logging never interferes with the instrument on-board logging. If the data logging is enabled on your 408 instrument, this logging will continue uninterrupted whenever OptiLink-II is running.

9.2.1 DATA ACQUISITION, LOGGING AND GRAPHING RATES


Logging and graphing rates (or frequencies) in OptiLink-II is very flexible, but could be also a bit confusing. This section explains the acquisition rate philosophy that is implemented in the software.

When the “Display Temperature” window is active, the software will continuously acquire and temporarily store the data in a very large software buffer; this buffer is being filled at a rate that is called “Acquisition Rate” (now fixed at 1 per second; averaging is possible, and this will show down the acquisition rate to one per minute. This buffer will keep filling as long as the “Acquire temperatures” window is active.

9.2.2 GRAPHS

This window allows presenting in graphical form both data 1) that is now being acquired, and 2) data previously acquired and that is saved in the instrument log memory (not implemented at the time of this writing). Similar to the previous windows whereby one can display up to 64 channels from 4 instruments, this window can also display up to 64 channels.

The example below shows a graph while data is being acquired.




The code behind this window is quite heavy, so this window may sometime appear non-responsive; please be patient!

Description of some options that are offered to you:

- You can adjust the colors of the window background, marker style, etc. With the 3D option, more variances are available, such as graph rotation, etc.
- The graphic can be zoomed, by first right-clicking anywhere in the graphic area, and select “Zoom”; then select an area that you would like to zoom with your mouse. The zoom is cancelled either after one minute, or by clicking the “Zoom out” button.
- The graphic can be panned, by first right-clicking anywhere in the graphic area, and select “Pan”; then use you mouse to move the graphic area.
- The window can be saved as an image (jpeg, png or gif), and can be printed.
- A “Pause Graph” option is useful if one want to examine in details some parts of the graphic. The graphic can be later resumed, without loss of data.

9.3 OPTICAL CHANNEL SETTINGS TOOL

This tool is useful to set up parameters that are related to the optical channel of your T/Guard system. You need to connect (only if you are not already connected) and then “Get Config” to download the current information, which will be displayed as follow (for an 8-channel system):




An offset can also be set for each optical channel; this is done indirectly by entering the temperature at which a probe should be. Please note that an offset will alter the instrument calibration, and should be done at your own risk. .


Once you have made the required changes to the displayed matrix of parameters, you must upload these changes by clicking “Apply Changes”.

9.4 RELAY CONDITIONS TOOL

Click the “Get Config” button to obtain the relay and relay conditions from the device; this should take less than 30 seconds. Progress will be indicated in the status messages (*in blue italics*):



Ultimately when the “Get Config” operation is successful, the grid, textbox and checkbox controls will be displayed with the downloaded values. There are 128 different conditions, 8 relay names and 8 relay failsafe states that can be edited and modified.



Normally you edit these settings, and then finally click the “Apply Changes” button to apply the changes to your T/Guard 408 device. When the changes have been uploaded correctly, you are shown a message confirming that the condition file was correctly sent to your device, and the table will be refreshed using the updated values.


On clicking the “Return to Main Menu” button, the application resets to its initial state. In most cases, that’s all you need to do.

9.5 DOWNLOAD FILES TOOL

This tool can be very useful to download these types of file:

- Status.txt: This is the status file described elsewhere in this document. It essentially gives an overview of all parameters of your system, that can easily be e-mailed or printed
- Temperatures.tem: This is the current logging file for temperature information. When this files reaches 65,000 lines long, it will be archived using the current date and time as a prefix to generate temperatures.tem file name, and a new temperatures.com file will open.
- Event.log: This is the same as the temperatures.com files, but for event information (alarms).
- Logging files, both for temperature and for event; these files are best read with Excel.
- Smart protocol related files, for Modbus (modbuspt.txt), DNP3 (dnp3pt.txt), IEC 60870-5 (60870pt.txt) and IEC 61850 (QGateway.cid); these files are text files, and can be read easily with Notepad or WordPad.
- Configuration file (.cfg); these files can be used to duplicate configurations from one 408 to another one. Use the “Upload Settings” tool to transfer these files to a new 408; see section 9.10.
- Messages includes information about the Linux operating information, that could be useful for Neoptix support in case of system malfunction; this file is not intended to be useful for the general users.

This shows the download tool:




When you download a file, its name is fixed. To avoid overwriting a file, it is suggested to rename the previously downloaded file first. Downloading large file can take some time... the download rate is approximately 1 kilobytes per second.

The log files (temperature and event) can be deleted, by right clicking on the file name, and selecting “Delete”.

9.6 GENERAL PARAMETERS

This window allows setting up the time and controlling logging.




9.7 ETHERNET PROTOCOL PARAMETERS

This window allows you to manage the licensed protocols over the Ethernet link. If your protocols are not licensed (product with the “-EPO” option), then this window will give you the option to control the Modbus protocol only. By default, these protocols are stopped, to save processor resources; it is suggested to keep them stopped unless you intend to use them. So at first, this window looks like this:




Once started, you will have more options available, such as id addresses, passwords, etc.; as illustrated here:



9.8 SERIAL PROTOCOL PARAMETERS

This window gives you the opportunity to control the serial communication parameters that are to be used when a specific protocol is used. Please note that these parameters will be available only for protocols that have been licensed for your specific instrument (however, Modbus is always available). You cannot start these protocols using OptiLink-II, as then there would be a conflict over what takes control of the serial port; the best way to start a serial protocol would be to use the local keypad, as explained in Section 7.10.



The DNP 3.0 protocol is available in either 16 or 32 bit; you should select 32 bit, unless your SCADA system supports only 16 bit.

9.9 FIRMWARE UPDATE TOOL

This tool provides a simple way to upgrade the 408 internal software code. Please note that an upgrade of a 408 can take 2 hours or more when using the OptiLink-II software. Your 408 must have already installed firmware version 3.51 or above to use this tool; if you have an older version, please contact Neoptix support for help.

To get an upgrade file, you must contact Neoptix support, at support@neoptix.com.

9.10 UPLOAD SETTINGS TOOL

This tool is useful for configuration T/Guard with similar a configuration, that would have been downloaded using the File Download" tool (.cfg files).

9.11 TROUBLESHOOTING

Here are some tricks you can try to fix any problems you may have with OptiLink-II, especially with starting the program:

- 1- Make sure the serial protocol on the *T/Guard 408* is set to "Neoptix".
- 2- Make sure the COM port is listed correctly in the Windows Device Manager. Check the port properties.
- 3- Use the appropriate cables:

During the development of the tool, the serial cabling we used was a USB to RS-485 converter, as recommended by the *T/Guard 408 Quick Start Guide* document:

The standard interface on the T/Guard 408 is a RS-485 port, not a RS-232 port. You will probably need a converter, either a RS-232 to RS-485 converter or a USB to RS-485 converter; the latter is recommended (Neoptix part number NXP-343).

Make sure your wiring matches your computer interface. For example, if your wiring is for 4-wires, make sure the whole cabling and software setting are set for full-duplex.

Be careful with cable length, especially when using a RS-232 interface (with a RS-485 to RS-232 converter): under certain circumstances, the baud rate can become as high as 115,000 baud, in which case a RS-232 link would be limited to only a few meters of cable (however, a real RS-485 link would be usable even with cable length of as much as 1 kilometer).

- 4- Make sure your duplex settings match.
- 5- Try connecting to the port with a HyperTerminal client to see if it is responsive.
- 6- This version of OptiLink-II requires that the 408 firmware version be 3.91 or above. If your firmware is older, consider upgrading it. Some functions will crash OptiLink-II if you try to use it with an older firmware version.
- 7- Try rebooting Windows.
- 8- Try re-installing your USB to serial port drivers on Windows.
- 9- When reinstalling OptiLink-II, you must first manually uninstall the current version; this can be done through the Programs and Features facility in Control Panel of Windows.

10 APPENDIX A – SOFTWARE UPGRADE VIA WEB INTERFACE


Firmware update operations are recommended only if there is a functional need that is not met. It is not recommended to upgrade the firmware of a T/Guard 408 for its own sake. Please follow the recommendation of Neoptix Support.

This appendix includes instructions to upgrade a 408XT, with an Ethernet port. If you have a 408 without an Ethernet port, please refer to the previous appendix.

If only for the file transfer speed alone, the web-enabled T/Guard 408 XT should be upgraded via the web page rather than the serial port.


Updates consist of only one file with the suffix .tar.gz and are provided by Neoptix Support. User preferences and network settings are not modified by a firmware update.

To select the provided firmware upload file, click on the 'Browse' button:




This will open a file chooser dialog window. Select the upgrade file provided by Neoptix (.tar.gz) file and click the 'Upload' button.

You will briefly have a progress bar while the file uploads:




This will be followed by a confirmation message:




At this point, there is no turning back. Keep your T/Guard 408 powered on!, as any power interruption may require to send back the unit to Neoptix for reformatting!

Clicking the 'OK' button to allow the firmware update; this may take up to 5 minutes. Once finished, the *T/Guard 408* will reboot without any user intervention.



This will be followed by a 'count down' web page:



This will redirect you to the *T/Guard 408* login web page with the new version of the software ready to go.

Important:

If your *T/Guard 408* seems to have become unresponsive after uploading the .tar.gz file, this is normal, you should not disturb it for at least 5 to 10 minutes, after which it will reboot by itself.

11 APPENDIX B – EXAMPLE OF A DOWNLOADED STATUS TEXT FILE

(Please note the following values do not reflect the precision or recommended settings of a device in the field, they are used here for illustration purposes only.)

```
T/Guard 408 - Status Report
2013/12/17 13:02:54 timezone: America/Montreal

Serial Number: 408-096A
Model Number: 408XT-08-SP1-EP1-M2
Firmware version: 3.90
Hardware code: 21
Calibration date: 2012/10/24
Up time: 135 day, 20 hours, 10 minutes, 7 seconds

----- Serial Interface -----
Serial Hardware: RS485-4w
Currently selected serial protocol: Neoptix

Settings for serial protocol: Neoptix
Address Id: None
Baud rate: 9600
Parity: None
Stop bits: 1

Settings for serial protocol: MODBUS
Address Id: 1
Baud rate: 9600
Parity: None
Stop bits: 2

Settings for serial protocol: IEC 60870-5-101
Address ID: 1
Parity: Even
Stop bits: 1

Settings for serial protocol: DNP 3.0
Address Id: (not used)
Baud rate: 9600
Parity: None
Stop bits: 1

----- Temperature Data Logging -----
Logging Enabled: yes
Logging rate: 300 seconds
Number of entries: 7321
Log file size: 520.8 kB
1% used (163.26 MB/1.561 GB)

----- Acquisition -----
Wtune: ON
Gskip: 5
Analog out err: Min level
Calibration type: Neoptix probe

----- Temperature Statistics -----
Unit: Celsius
Global Highest: 27.0
Global Lowest: 25.8

----- Channel Settings -----
Chan name Enable   Zero      Span      Offset
LV-PhB      Y         0.0       160.0     0.0
Channel2    Y        -100.0    400.0     0.0
Channel3    Y        -100.0    400.0     0.0
Channel4    Y        -100.0    400.0     0.0
Channel5    Y        -100.0    400.0     0.0
Channel6    Y        -100.0    400.0     0.0
Channel7    Y        -100.0    400.0     0.0
Channel8    Y        -100.0    400.0     0.0

----- Signal Quality -----
```

CH1: 100%, ratio:2.51, lamp:165, CCD:80ms (auto), 26.2 C
CH2: 100%, ratio:2.39, lamp:165, CCD:80ms (auto), 26.1 C
CH3: 100%, ratio:2.56, lamp:170, CCD:60ms (auto), 26.8 C
CH4: 100%, ratio:2.56, lamp:170, CCD:60ms (auto), 26.4 C
CH5: 100%, ratio:2.36, lamp:170, CCD:60ms (auto), 27.0 C
CH6: 100%, ratio:2.29, lamp:170, CCD:60ms (auto), 26.1 C
CH7: 100%, ratio:2.65, lamp:170, CCD:60ms (auto), 26.9 C
CH8: 100%, ratio:2.21, lamp:170, CCD:60ms (auto), 25.8 C

----- Relays -----
#1: Relay name 1 de-energized
#2: Relay name 2 de-energized
#3: Relay name 3 de-energized
#4: Relay name 4 de-energized
#5: Relay name 5 energized
#6: Relay name 6 de-energized
#7: Relay name 7 de-energized
#8: Relay name 8 de-energized

----- Relay conditions ----- (only enabled conditions are shown)

#CONDITION_ID	RELAY_NUMBER	CHANNEL_NUMBER	HYSTERESIS	TEMPERATURE_THRESHOLD	TYPE	NAME
1	1	Highest	5	65	LOTH	Cond.#1
2	2	Highest	5	75	LOTH	Cond.#2
3	1	Highest	5	120	LOTH	Cond.#3

----- List of registered web users -----
guest
neoptix

----- TransLife(tm) Results -----
Delta: 6.5
Unity temperature: 110.0 Celsius
Years of anticipated life: 20
Number of minutes in operation: 43043
Number of minutes consumed: 43043
NTP started: no

----- Licensed Protocols -----
Licensed serial protocols: Neoptix ASCII, 60870, DNP3, Modbus
Licensed Ethernet protocols: 60870, Modbus, DNP3, 61850

(end)

12 APPENDIX C – USING *OPTILINK* TO COMMUNICATE WITH THE *T/GUARD 408*

12.1 USING *OPTILINK*

Note: We have used the name NeoLink before; please note that NeoLink and OptiLink are the same software package.

Note: OptiLink can also be used with the *T/Guard 408XT*, but only through its serial port (OptiLink cannot be used over an Ethernet network).

OptiLink is a Windows program by Qualitrol that provides a convenient graphic user interface to the *T/Guard 408* as well as other devices built by Neoptix/Qualitrol. It is offered in two versions:

- The “Lite” version now ships as a standard item with every instrument, it supports only one instrument at a time;
- The “Pro” version includes more features and support more instruments and/or channels simultaneously.

Regarding the *T/Guard 408* specifically, the “Lite” version does not provide upload or download relay configuration buttons. These features are only available in the “Pro” version.


Please contact your Qualitrol Representative to purchase a serial number registration for the “Pro” version.

Before starting, make sure you are connected to a running *T/Guard 408* through a serial port to your Windows PC.


After installing *OptiLink* with a standard setup.exe installation wizard, you will be able to launch this program in Windows 7 by doing: *Start button > All Programs > Qualitrol > OptiLink > OptiLink*

Up to 4 instruments can be connected at the same time to OptiLink (each instrument must have its own serial port).

Initially a blank *OptiLink* window appears while it scans all COM ports for a device it recognizes. After a few seconds, it will have detected the *T/Guard 408*. Click on the tab that indicates “408”.



This will present the following interface which allows you to change temperature units as well as some other settings in a convenient fashion:



The top portion of the window gives information about the specifics of the thermometer, such as:

- COM Port number
- Serial Number of the *T/Guard 408*
- Calibration date

The *On/Off* check box allows you to enable or disable a channel. The change is applied as soon as you uncheck a checkbox.

Name: Up to 16 characters. You can enter a probe name here that suits your application. This value is not saved to the *T/Guard 408* device, it is a convenience provided by *OptiLink*.

The Log checkbox does not refer to the logging made by the *T/Guard 408* device itself; it refers to custom logging done on the Windows PC running *OptiLink*, in the file that is defined in the bottom left corner titled "*Data logging*". On the *T/Guard 408*, logging is an "all or nothing" proposition, while *OptiLink* offers a more granular control on what is logged.

The Chart checkbox allows selecting channels that will be displayed in the popup windows that can be summoned by clicking on one of the four selections in the bottom right "*Chart*" section.

The two "*Alarms*" settings are once again local to the Windows PC, nothing is forwarded to the *T/Guard 408*. Here you are allowed to set alarm limits. When one or more alarms are detected, a message is given at the bottom of the main window (must be in Acquisition mode). For a given channel, alarms are monitored only when its corresponding "*Chart*" or "*Log*" checkbox is checked, in the Configuration window pane. Alarms are monitored only when Acquisition is active.


Analog Outputs: Allows configuring the analog output parameters, Zero and Span. The analog zero is the minimum value of analog output. The analog span can range from 1.0 to 1000.0, in temperature units (Celsius or Fahrenheit). The default values on the *T/Guard 408* are -100 for the Zero and 400 for the Span. This is configurable per channel. Under the covers, a change here will send identical commands through the serial port to the *T/Guard 408* device as the ASCII Neoptix protocol "*s*" and "*z*" commands.

Offset: Allows adding an offset to a channel. To perform an offset adjustment:

- Click the "Offset Adjust" button ("+") that is just next to the channel number you want to calibrate.

- Type in the "Set Point" box the actual temperature that you would like to force for this channel (this temperature is normally obtained using an accurate NIST-certified primary temperature reference).
- Press the "OK" button to activate the reference temperature. The "Offset" value will reset to its new value, as a result of your new forced temperature; this new offset is now displayed in the main window.

For example, suppose channel 4 always displays one degree less than it should and is currently displaying "24.0" degrees C. Clicking the offset button for this channel will bring up a selector window; in that window, scroll to 25.0 which is the value that *should* be displayed on channel 4:




Click *OK* and the *T/Guard 408* will apply the offset of 1 and display 25.0

A "Config Modbus" button is available to configure the serial Modbus parameters, such as baud rate, number of stop bits, and so forth.


OptiLink also includes a convenient Console that can be used as an alternative to HyperTerminal, especially when you are already using OptiLink. You can invoke it by selecting Window and the Open Console from the menu bar (you must be in non-acquisition mode to use the Console).

Warning: This Console can only be used for serial command that do not involve file transfer; in other words, it can be used only when the query and answer are simple ASCII characters.



12.2 LOGGING TEMPERATURES IN WINDOWS WITH OPTILINK


To log, click on the *Acquisition* tab. This will enable the "Start" button:



Here you can select the location of the log file and vary the speed of the acquisition rate by clicking on the “Save As...” button. For information, the current filename is displayed just below this button. Default file location is “My Documents”, for Windows 7 and above.

The file format of the generated log file will be a plain text file with the .tem file extension. Click the “Start” button to begin logging.

Alternately, if you check the “DDE Excel” checkbox, instead of a plain text file as the target, you can log directly to an Excel 2007 spreadsheet instead. Please note, this requires either an English or French language version of Microsoft Excel to be pre-installed on the desktop.




Click the Start button to begin logging.

IMPORTANT, the “DDE Excel” functionality requires:

- Either the French or English language versions of Excel to be installed on the Windows 7 PC (note: most international versions of Excel should select English)
- You must correctly identify the language version of Excel when prompted by *OptiLink*
- Click the “.xlsx format” checkbox if you are using Excel version 2007 or later
- It is recommended to select a file name for the target spreadsheet that does not exist yet and to close all other open spreadsheets before beginning
- If you select a file name that already exists, data will be appended to the existing data, after a 2 line header has been added


12.3 VIEWING TEMPERATURE DATA IN OPTILINK

Temperature values can be displayed on your computer screen in a number of ways. Click one of the four "Chart" button to active one or more of these windows.



Note that more than one window type can be displayed simultaneously; in addition, you can log temperatures to a file independently from these display windows. Note that each of these 2 modes have each then own acquisition time base.


To display temperature trends, click the "Chart" button to get the following window:



Adjust the "Refresh Rate" and Min / Max to suit your viewing needs. The minimum refresh rate is 0.2 second in OptiLink; however the *T/Guard 408* will send temperature data once every two seconds.

Note that the setting of curve colors and other parameters must be done in the "System Configuration" window pane. Up to 64 trends can be displayed.

Displaying analog thermometers can be achieved by clicking the "Thermometer" style button; the following window will appear:



All thermometers share the same Min / Max reading setting. Refresh rate is fixed at 1.0 sec. The size of this window will change depending on the number of channels to display. Up to 16 thermometers can be shown; if you want to display more than 16 channels, only the first 16 detected channels will be shown (note that any channel that has its "Chart" checkbox unchecked, in the main window, will not be shown).

If an alarm is active for a channel, the corresponding thermometer numbers will change color: **blue** for a low temperature alarm, or **red** for a high temperature alarm.

12.4 RECOMMENDED CONFIGURATION, FOR TRANSFORMER APPLICATIONS

For transformer applications, it is recommended that the following parameters be set as follows:

Feature	Benefit description	Command
Ignore bad scans	This allows for better stability of the analog outputs, when working with “weak” or “marginal” probes.	Gskip = 5
Auto-tune CCD	Optimize the CCD operation, especially useful when working with “weak” or “marginal” probes. Has the advantage also to lower the voltage on the internal lamps, thus improve long-term system reliability.	wtune+
Analog output zero	Adjust the analog output zero setting, for each channel. Warning: this command must be sent individually for each channel.	Zero1 = -50 Zero2 = -50, etc.
Analog output span	Adjust the analog output span setting, for each channel. Warning: this command must be sent individually for each channel.	Span1 = +200 Span2 = +200, etc.
Analog output, if no probes	Adjust the analog output behavior, when no probe is detected. Warning: this command must be sent individually for each channel.	Set as required

All of these command settings can be confirmed with the web browser interface or by ASCII commands through the serial port.

12.4.1 INTERPRETATION OF PROBE INTENSITY RESULTS

The Neoptix T/Guard systems are fitted with a function that gives an evaluation about probe signal strength or signal quality index; in Neoptix jargon, this is called the “y” command.

Feature	Benefit description	Command
Ignore bad scans	This allows for better stability of the analog outputs, when working with “weak” or “marginal” probes.	Gskip = 5
Auto-tune CCD	Optimize the CCD operation, especially useful when working with “weak” or “marginal” probes. Has the advantage also to lower the voltage on the internal lamps, thus improve long-term system reliability. This is equivalent to an AGC (automatic gain control) algorithm.	wtune+
Analog output zero	Adjust the analog output zero setting, for each channel. Warning: this command must be sent individually for each channel. This example with display temperatures in the range from -50 to +150 °C.	Zero1 = -50 Zero2 = -50, etc.
Analog output span	Adjust the analog output span setting, for each channel. Warning: this command must be sent individually for each channel.	Span1 = +200 Span2 = +200, etc.
Analog output, if no probes	Adjust the analog output behavior, when no probe is detected. Warning: this command must be sent individually for each channel.	Set as required

Typically, the following information is displayed:

```
CH1: 100%, ratio:2.68, lamp:165, CCD:80, (auto)12
```

CH1 indicates the channel number (typically 1 to 8, for an 8-channel T/Guard 408 system, or 1 to 16 for a 16-channel system).

The power % value, ranging from 0 to 100%; this parameter is an amalgamation of the 3 parameters (Ratio, Lamp attenuation and CCD time), that simplifies the interpretation of optical signal strength of a probe link. Refer to the Neoptix document G1009, "Probe Installation Guide", for more information on how to use this global parameter when testing probes.

Ratio indicates the power strength and can span from about +0.3 to +2.8. You can interpret it approximately as follows:

- 0.3 to 1.07: no probe is detected
- 1.07 to 1.25: a probe is probably present, but exhibits a very weak signal; its reading is usually rejected, as it is considered as unreliable
- 1.25 to 3.3: a good probe is present (the higher the ratio the more healthy the probe).

Lamp attenuation gives an indication about the white light lamp intensity for this channel. It ranges from 210 (weak lamp) to 100 (strong or intense lamp). A weak lamp is usually preferred and indicates a "healthy" probe.

The CCD time (CCD = charge couple device) gives the optical integration time in millisecond; it can range from 40 to 500 ms. A weak probe will normally have a long integration time.

To summarize, a very good probe is characterized by a good quality index ratio (>1.8), then by a high lamp attenuation (>200) and finally by a short integration time (<200ms). Also, dirty connectors will contribute to lower probe strength; always assure that all fiber connections are clean before evaluating probe performance.

Warning: After a power-on or after changing (or exchanging) probes or extension cords, allow sufficient time for the T/Guard optimization process to complete before invoking the y command; in most cases, it may take as much as 15 seconds for this optimization to complete, especially when the number of enabled channels is high, e.g., 8 or more.

¹² The %power value will be displayed only if wtune+ is activated, in which case "(auto)", instead of "(fixed)", is also displayed.

13 APPENDIX D – MODBUS COMMUNICATION PROTOCOL

The Modbus protocol is a messaging structure developed by Modicon in 1979, used to establish master-slave / client-server communication between intelligent devices. It is a de-facto standard, truly open and the most widely used network protocol in the industrial manufacturing environment. The Modbus protocol provides an industry standard method that devices can use for parsing messages. The Neoptix *T/Guard-408* supports the Modbus protocol over a serial line.

A master-slave type system has one node (the master node) that issues explicit commands to one of the “slave” nodes and processes responses. Slave nodes (such as *T/Guard* systems: *T/Guard*, *T/Guard+*, *T/Guard 408*, *T/Guard-Link*, *T/Guard 405*, etc.) will not transmit data without a request from the master node, and do not communicate with other slaves. Up to 32 units can be connected on a single RS-485 bus.

At the physical level, systems using Modbus over serial lines may employ different physical interfaces, such as RS-485, or RS-232. The RS-485 two-wire interface is the most common. As a standard feature, a RS-485 four-wire interface is fitted on the *T/Guard-408* (can be configured by the user as a two-wire interface).

Neoptix has experienced some communication problems when configuring multiple Modbus RS-485 systems together. This is usually caused by unstable grounding problems, such as what can be encountered when dealing with power transformers. To solve these problems, your RS-485 lines should be opto-isolated before connecting them to the master Modbus bus.

13.1 CONFIGURING THE MODBUS OPTION

Configuring and enabling the Modbus option must be done prior to using the protocol; this can be done using the local keypad or with the web interface (*408XT* only).

The default or suggested parameter values are:

- Stop bit: 1 (fixed)¹³
- Parity: even
- Baud rate (BR): 9,600 (baud rates higher than 19,200 are not recommended)
- Address ID: 1 to 247 (each *T/Guard* must have a unique node address). Addresses ID of 248-255 are also accepted, although these are not respecting the Modbus protocol.

13.2 SUPPORTED SERIAL TRANSMISSION MODE

The transmission mode defines the bit contents of the message bytes transmitted along the network, and how the message information is to be packed into the message stream and decoded. The current implementation of Neoptix Modbus supports only the RTU mode.

13.3 RTU TRANSMISSION MODE

Coding system	8 bit binary
Number of data bits per character	11 bits start bits – 1 data bits – 8 parity bits – 0 or 1 (even or odd) stop bits – 1 (2 if no parity bit used)
Parity	None or even parity

¹³ The 408 will allow you to configure it with any combination of stop and parity bits, even if this is not according to the Modbus standard. However, a received character string that does not respect the specified stop and parity bits will be rejected.

Bit transfer rate	9600 or 19200 Baud
Duplex	Full or Half
Error checking	CRC (cyclic redundancy check)
Polynomial	(CRC-16 101000000000001)
Bit transfer order	LSBit first, MSByte first
End of message	Idle line for 3.5 or more characters.

The link layer includes the following properties /behaviors:

- Slave address recognition
- Start / End of Frame detection
- CRC-16 generation / checking
- Transmit / receive message time-out
- Framing error detection.

13.4 MODBUS FUNCTION CODE AND REGISTER ADDRESSES

Registers can be read or written singly or in groups (16 registers maximum by read or write cycles). However trying to read or write to reserved registers will generate exception errors.

The Modbus information is also included in a different document; see G1030, Smart Protocol Reference Guide. Do not hesitate to contact Neoptix for a copy.

13.4.1 MODBUS PROTOCOL MAP REGISTERS

Warning: The following tables include the content of legacy registers, in yellow; these are given for reference purposes only. For new Modbus implementation, Neoptix strongly recommends to avoid using these older legacy registers. Legacy registers are not supported with Modbus over Ethernet.

- All values are in decimal, unless hex format is specified.
- All temperatures values are given in Celsius degrees.

Supported Function Codes

Function code (ModScan)	Name	Usage
02 (02h)	Read Discrete Inputs	Optical signal present
03 (03h)	Read Holding Register	Device configuration and temperatures
04 (04h)	Read Input Register	Measured temperature values
06 (06h)	Write Single Register	Device configuration
16 (10h)	Write Multiple Registers	Device configuration

Name	SERIAL			ETHERNET		Description (type)
	Reg Type Modscan	Read Write	408	Read Write	408	
Device Internal temperature	03	R	41			
Number of channels	03	R	42	R	42	(Signed 16 bit integer)
Soft version	03	R	43	R	43	(Signed 16 bit integer)
Soft revision	03	R	44	R	44	(Signed 16 bit integer)

	Device type	03	R	45	R	45	= 17 (for the 408)
	Mode A	03	R	46	R	46	(Signed 16 bit integer)
	Mode B	03	R	47	R	47	(Signed 16 bit integer)
Power %	Powerpct channel 1	03	R	101	R	101	Power % (Signed 16 bit integer)
	Powerpct channel 2	03	R	102	R	102	
	Powerpct channel 3	03	R	103	R	103	
	Powerpct channel 4	03	R	104	R	104	
	Powerpct channel 5	03	R	105	R	105	
	Powerpct channel 6	03	R	106	R	106	
	Powerpct channel 7	03	R	107	R	107	
	Powerpct channel 8	03	R	108	R	108	
	Powerpct channel 9	03	R	109	R	109	
	Powerpct channel 10	03	R	110	R	110	
	Powerpct channel 11	03	R	111	R	111	
	Powerpct channel 12	03	R	112	R	112	
	Powerpct channel 13	03	R	113	R	113	
	Powerpct channel 14	03	R	114	R	114	
	Powerpct channel 15	03	R	115	R	115	
	Powerpct channel 16	03	R	116	R	116	
Lamp attenuation	Lamp attn Channel 1	03	R	201	R	201	Value between 0 and 255
	Lamp attn Channel 2	03	R	202	R	202	
	Lamp attn Channel 3	03	R	203	R	203	
	Lamp attn Channel 4	03	R	204	R	204	
	Lamp attn Channel 5	03	R	205	R	205	
	Lamp attn Channel 6	03	R	206	R	206	
	Lamp attn Channel 7	03	R	207	R	207	
	Lamp attn Channel 8	03	R	208	R	208	
	Lamp attn Channel 9	03	R	209	R	209	
	Lamp attn Channel 10	03	R	210	R	210	
	Lamp attn Channel 11	03	R	211	R	211	
	Lamp attn Channel 12	03	R	212	R	212	
	Lamp attn Channel 13	03	R	213	R	213	
	Lamp attn Channel 14	03	R	214	R	214	
	Lamp attn Channel 15	03	R	215	R	215	
	Lamp attn Channel 16	03	R	216	R	216	
CCD Time	CCD time Channel 1	03	R	301	R	301	Non-auto (wtune-) = 50
	CCD time Channel 2	03	R	302	R	302	Auto (wtune+) = 20 to 500, Signed 16 bit integer
	CCD time Channel 3	03	R	303	R	303	
	CCD time Channel 4	03	R	304	R	304	
	CCD time Channel 5	03	R	305	R	305	
	CCD time Channel 6	03	R	306	R	306	
	CCD time Channel 7	03	R	307	R	307	
	CCD time Channel 8	03	R	308	R	308	
	CCD time Channel 9	03	R	309	R	309	
	CCD time Channel 10	03	R	310	R	310	
	CCD time Channel 11	03	R	311	R	311	
	CCD time Channel 12	03	R	312	R	312	
	CCD time Channel 13	03	R	313	R	313	
	CCD time Channel 14	03	R	314	R	314	
	CCD time Channel 15	03	R	315	R	315	
	CCD time Channel 16	03	R	316	R	316	
Ratio (signal strength)	Ratio Channel 1	03	R	401	R	401	Ratio * 100 (Signed 16 bit integer)
	Ratio Channel 2	03	R	402	R	402	
	Ratio Channel 3	03	R	403	R	403	
	Ratio Channel 4	03	R	404	R	404	
	Ratio Channel 5	03	R	405	R	405	

	Ratio Channel 6	03	R	406	R	406	
	Ratio Channel 7	03	R	407	R	407	
	Ratio Channel 8	03	R	408	R	408	
	Ratio Channel 9	03	R	409	R	409	
	Ratio Channel 10	03	R	410	R	410	
	Ratio Channel 11	03	R	411	R	411	
	Ratio Channel 12	03	R	412	R	412	
	Ratio Channel 13	03	R	413	R	413	
	Ratio Channel 14	03	R	414	R	414	
	Ratio Channel 15	03	R	415	R	415	
	Ratio Channel 16	03	R	416	R	416	
Analog zero	Analog zero Channel 1	03	R/W	2001	R	2001	Temperature * 10, Signed 16 bit integer
	Analog zero Channel 2	03	R/W	2002	R	2002	
	Analog zero Channel 3	03	R/W	2003	R	2003	
	Analog zero Channel 4	03	R/W	2004	R	2004	
	Analog zero Channel 5	03	R/W	2005	R	2005	
	Analog zero Channel 6	03	R/W	2006	R	2006	
	Analog zero Channel 7	03	R/W	2007	R	2007	
	Analog zero Channel 8	03	R/W	2008	R	2008	
	Analog zero Channel 9	03	R/W	2009	R	2009	
	Analog zero Channel 10	03	R/W	2010	R	2010	
	Analog zero Channel 11	03	R/W	2011	R	2011	
	Analog zero Channel 12	03	R/W	2012	R	2012	
	Analog zero Channel 13	03	R/W	2013	R	2013	
	Analog zero Channel 14	03	R/W	2014	R	2014	
	Analog zero Channel 15	03	R/W	2015	R	2015	
	Analog zero Channel 16	03	R/W	2016	R	2016	
Analog span	Analog span Channel 1	03	R/W	2101	R	2101	Temperature * 10, Signed 16 bit integer
	Analog span Channel 2	03	R/W	2102	R	2102	
	Analog span Channel 3	03	R/W	2103	R	2103	
	Analog span Channel 4	03	R/W	2104	R	2104	
	Analog span Channel 5	03	R/W	2105	R	2105	
	Analog span Channel 6	03	R/W	2106	R	2106	
	Analog span Channel 7	03	R/W	2107	R	2107	
	Analog span Channel 8	03	R/W	2108	R	2108	
	Analog span Channel 9	03	R/W	2109	R	2109	
	Analog span Channel 10	03	R/W	2110	R	2110	
	Analog span Channel 11	03	R/W	2111	R	2111	
	Analog span Channel 12	03	R/W	2112	R	2112	
	Analog span Channel 13	03	R/W	2113	R	2113	
	Analog span Channel 14	03	R/W	2114	R	2114	
	Analog span Channel 15	03	R/W	2115	R	2115	
	Analog span Channel 16	03	R/W	2116	R	2116	
Offset on channel	Offset Channel 1	03	R/W	2201	R	2201	Temperature * 10, Signed 16 bit integer
	Offset Channel 2	03	R/W	2202	R	2202	
	Offset Channel 3	03	R/W	2203	R	2203	
	Offset Channel 4	03	R/W	2204	R	2204	
	Offset Channel 5	03	R/W	2205	R	2205	
	Offset Channel 6	03	R/W	2206	R	2206	
	Offset Channel 7	03	R/W	2207	R	2207	
	Offset Channel 8	03	R/W	2208	R	2208	
	Offset Channel 9	03	R/W	2209	R	2209	
	Offset Channel 10	03	R/W	2210	R	2210	
	Offset Channel 11	03	R/W	2211	R	2211	
	Offset Channel 12	03	R/W	2212	R	2212	
	Offset Channel 13	03	R/W	2213	R	2213	
	Offset Channel 14	03	R/W	2214	R	2214	

	Offset Channel 15	03	R/W	2215	R	2215	
	Offset Channel 16	03	R/W	2216	R	2216	
Enable channel	Enable Channel 1	03	R/W	2301	R	2301	0 = disable ; 1 = enable
	Enable Channel 2	03	R/W	2302	R	2302	
	Enable Channel 3	03	R/W	2303	R	2303	
	Enable Channel 4	03	R/W	2304	R	2304	
	Enable Channel 5	03	R/W	2305	R	2305	
	Enable Channel 6	03	R/W	2306	R	2306	
	Enable Channel 7	03	R/W	2307	R	2307	
	Enable Channel 8	03	R/W	2308	R	2308	
	Enable Channel 9	03	R/W	2309	R	2309	
	Enable Channel 10	03	R/W	2310	R	2310	
	Enable Channel 11	03	R/W	2311	R	2311	
	Enable Channel 12	03	R/W	2312	R	2312	
	Enable Channel 13	03	R/W	2313	R	2313	
	Enable Channel 14	03	R/W	2314	R	2314	
	Enable Channel 15	03	R/W	2315	R	2315	
	Enable Channel 16	03	R/W	2316	R	2316	
Relay failsafe status	Fail safe Relay 1	03	R/W	2401	R	2401	0 = disable ; 1 = enable
	Fail safe Relay 2	03	R/W	2402	R	2402	
	Fail safe Relay 3	03	R/W	2403	R	2403	
	Fail safe Relay 4	03	R/W	2404	R	2404	
	Fail safe Relay 5	03	R/W	2405	R	2405	
	Fail safe Relay 6	03	R/W	2406	R	2406	
	Fail safe Relay 7	03	R/W	2407	R	2407	
	Fail safe Relay 8	03	R/W	2408	R	2408	
	Calibration type	03	R/W	2501	R	2501	0 = Neoptix ; 1 = Nortech Fibronic
	Unit	03	R/W	2502	R	2502	0 = °C ; 1 = °F
	wtune	03	R/W	2504	R	2504	0 = disable ; 1 = enable (optimize CCD time)
	Analog out if error	03	R/W	2505	R	2505	0 = max if no signal ; 1 = min if no signal
TransLife™	TransLife Delta	03	R		R	2601	* 10 (Signed 16 bit integer)
	TransLife Unity Temp	03	R		R	2603	Temperature * 100, Signed 16 bit integer
	TransLife Years Of Life	03	R		R	2605	
	TransLife Minutes Before	03	R		R	2607	
	TransLife Minutes After	03	R		R	2609	
Temperature, actual	Channel 1 temperature	04	R	1	R	1	Temperature * 10, Signed 16 bit integer
	Channel 2 temperature	04	R	2	R	2	
	Channel 3 temperature	04	R	3	R	3	
	Channel 4 temperature	04	R	4	R	4	
	Channel 5 temperature	04	R	5	R	5	
	Channel 6 temperature	04	R	6	R	6	
	Channel 7 temperature	04	R	7	R	7	
	Channel 8 temperature	04	R	8	R	8	
	Channel 9 temperature	04	R	9	R	9	
	Channel 10 temperature	04	R	10	R	10	
	Channel 11 temperature	04	R	11	R	11	
	Channel 12 temperature	04	R	12	R	12	
	Channel 13 temperature	04	R	13	R	13	
	Channel 14 temperature	04	R	14	R	14	
	Channel 15 temperature	04	R	15	R	15	
	Channel 16 temperature	04	R	16	R	16	
					R	17	
Channel	Channel 1 status	02	R	17	R	17	0 = No signal * 1 = Probe detected

status	Channel 2 status	02	R	18	R	18	
	Channel 3 status	02	R	19	R	19	
	Channel 4 status	02	R	20	R	20	
	Channel 5 status	02	R	21	R	21	
	Channel 6 status	02	R	22	R	22	
	Channel 7 status	02	R	23	R	23	
	Channel 8 status	02	R	24	R	24	
	Channel 9 status	02	R	25	R	25	
	Channel 10 status	02	R	26	R	26	
	Channel 11 status	02	R	27	R	27	
	Channel 12 status	02	R	28	R	28	
	Channel 13 status	02	R	29	R	29	
	Channel 14 status	02	R	30	R	30	
	Channel 15 status	02	R	31	R	31	
	Channel 16 status	02	R	32	R	32	
	Relay status	Relay 1 status	02	R	201	R	201
Relay 2 status		02	R	202	R	202	
Relay 3 status		02	R	203	R	203	
Relay 4 status		02	R	204	R	204	
Relay 5 status		02	R	205	R	205	
Relay 6 status		02	R	206	R	206	
Relay 7 status		02	R	207	R	207	
Relay 8 status		02	R	208	R	208	

13.5 MODBUS EXCEPTION CODES

The *T/Guard 408* Modbus operation supports 2 exception codes.


Exception code	DESCRIPTION
01	Function not supported
02	Register number out of range

If a parity error or CRC error is detected in a received message, the *T/Guard 408* simply ignores this message (no response is sent).

13.6 MODSCAN EXAMPLES

ModScan can be purchased from <http://www.win-tech.com/html/modscan32.htm>. *ModScan* is a good and simple program that can be used to exercise Modbus links. Furthermore, it can also be used to perform some simple data logging. Please note that this program must be purchased separately, it is not supplied as a standard item with the *T/Guard 408* system. See section 13.9 below.


When started, the following screen will appear:



Make sure your *T/Guard 408* system is connected to your PC computer. Because most PC computers do not have a RS-485 port, you will need a USB to RS-485 adapter (available for purchase as an option from Neoptix).

You must first connect to your PC, by selecting *Connection* from the main menu, and then *Connect*.


The following window will open:



Make sure the COM port, baud rate and parity are set correctly (*Word Length* value should always be 8). Click OK.


Next, make sure “*Device Id:*” is set to the proper Modbus node address.

You should now be connected and ready to monitor data. For example, the following figure shows values for 10 input registers; you can see that temperature on channel # 1 is 25.2°C, and so forth.




13.7 USING MODSCAN OVER ETHERNET

Using ModScan (version 8.A00-10, March 2014) over the Ethernet is quite simple. Instead of selecting a Com port when trying to connect, select instead “Remote modbus TCP/IP Server”, as shown here:



Click OK. The rest is all the same as above. Please remember that you can concurrently use the web server and Modbus! The main acquisition window should be as follows:




When using ModScan, pay attention to these points:

- The parameter “Point Type” must be set to the type of variables that you want to read; see Smart Protocol User Guide, Document # G1030rxx for more information
- The parameter “Length” must not be too large; otherwise ModScan will return an error if you are trying to read non-existent registers
- The Modbus option must be enabled in the Ethernet Protocols web page; see Section 8.7.8. If using the serial port, make sure the serial port communication mode is set to “Modbus”; this can be done using OptiLink-II, see section 9.8
- The display mode should be set to Integer (Setup → Display Options → Integer)
- ModScan starts to count register with 1, not 0. The documentation in G1030 starts counting register at 0!
- Transmission mode should be STANDARD RTU. ASCII mode is not supported.

13.8 MONITORING MULTIPLE T/GUARD 408 SYSTEMS


ModScan can be used to monitor either multiple T/Guard 408 system (as shown below), or multiple type of variables, for example, the input registers and coil status. To do this, simply open multiple windows within ModScan (from the main menu bar, select File and then New).

Warning: if you are opening many windows at once, it may be a good idea to slow down the data refresh rate. This can be done by selecting Setup from the main menu, then Data Definition, and then by entering something like 5 seconds in the Scan rate box; please remember than you will need to perform this setting for each opened window.



13.8.1 WRITING PARAMETERS

To write data, you must select *Holding Register*. Then, from the main menu bar, select *Setup*, then *Extended*, then *Preset Regs*. Make sure the value of “Number of Points” is set to the number of parameters you want to change. Make sure the Slave Device is corrected set (node number), and that the Address points to the register address you want to modify. For example, to change a temperature value from 200 to 50, you will enter (remember to multiply the temperature value by 10):




Click update to “write” your new value.


13.8.2 DATA LOGGING

ModScan allows you to log either in a text file (.txt) or a database file (.mdb, Microsoft Access database format). Both are similar. Here is a quick example, saving to a text file.

Select Setup from the main menu, and then Text Capture. In the Save As box, enter a proper file name (if using Windows Vista, make sure your file is not saved in the Program File directory). In the next window, enter the frequency at which you want to log data:



Data logging will automatically start. To end logging, select *Setup* and then *Capture Off*. The saved file can then be open using WordPad (do not use Notepad). Typically, the saved data should look like this:



Warning: If you have multiple *ModScan* windows open, then you will have to start multiple logging sessions

13.9 USING MODSCAN TRIAL VERSION TO TEST THE MODBUS SERIAL PROTOCOL ON THE 408

The file modscan32.zip is on the latest Neoptix CDROM (CD0014), or from the web site given in Section 13.6. Unzip the file modscan32.zip to a directory on your local hard drive (not a network shared drive). Set up your T/Guard 408 to the MODBUS serial protocol via the keypad “PrtL” menu (Section 7.10), with OptiLink-II (Section 9.6) or via the web page for a 408XT.


In Windows Explorer, double-click ModScan32.exe to start it. You should get:




Just click the *OK* button. Next you get:




Wait 3 seconds for the *OK* button to be enabled then click the *OK* button. Next you get:




Again, wait 3 seconds for the *OK* button to be enabled then click the *OK* button. You get:




Now, we need to customize ModScan. Change settings to the following:




Next, click menu *Connection* > *Connect* and set as follows (choose your own COM port of course, according to your PC).



Click the *OK* button. You should now get:



Click the *OK* button. You should see values such as the following:



Contact WinTech Software (<http://www.win-tech.com/html/modscan32.htm>) if you want to purchase this product.

14 APPENDIX E – OPTIONAL RS-485 TO USB CONVERTER

As most PC computers today don't have serial ports, Neoptix recommends using a RS-485 to USB converter (also called adapter). It works great with all *T/Guard*, *T/Guard 405*, *T/Guard-Link*, *T/Guard 408* and *T/Guard+* systems.

This converter works for both 2W and 4W RS-485 installations; no external power supply is required. It also offers 2000V RMS optical isolation, which is ideal for electrically noisy applications or when grounding may be a problem. The following figure shows this adapter (when purchased from Neoptix, the adapter will be fitted with a DB9 connector suitable for use for both 2W and 4W applications):



Note that this converter requires a special software driver that needs to be installed before you use the device; you will find all details on the CD that comes with the unit.

Furthermore, the converter has 4 dip switches that need to be configured depending on your exact installation: there are 2 possibilities, as follows:

- a) If you have a 2W (2-wire, also called “half-duplex”) installation, then the four dip switches must be set as follows:
 - a. Switch 1 must be on (RS-485 mode)
 - b. Switch 2 must be on (Echo Off)
 - c. Switch 3 must be on (2 Wire mode)
 - d. Switch 4 must be on (2 Wire mode).

- b) If you have a 4W (4-wire, also called “full-duplex”) installation, then the four dip switches must be set as follows:
 - a. Switch 1 must be on (RS-485 mode)
 - b. Switch 2 must be off (Echo On)
 - c. Switch 3 must be off (4 Wire mode)
 - d. Switch 4 must be off (4 Wire mode).

Warning: When dealing with very long cables (e.g., more than 300 meters), your RS-485 network might need a termination resistor (typically 120Ω).

Please consult Neoptix / Qualitrol for more details.

15 APPENDIX F – COMMISSIONING PROCEDURE FOR NEOPTIX T/GUARD-408

15.1 INTRODUCTION

This procedure should be used to confirm the good operation of a Neoptix T/Guard-408 system, which is already installed in a transformer control cabinet; this means that the system is already connected to a suitable 90-260 VAC supply, and has been completely tested by the transformer manufacturer at his manufacturing plant. This procedure is intended to be used by the transformer end user (utility). This procedure should be used in conjunction with the Neoptix applicable documentation, in particular this user guide.

15.2 REQUIRED TOOLS

These tools will be required to perform the procedure completely:

- A PC with a serial port (with a USB adapter)
 - OptiLink or OptiLink-II software, must be already installed on your PC
 - These software packages are either on the Neoptix CD or DVD that should have been shipped with the transformer, or you can download them from the web (see instructions below)
 - For the 408XT, an Ethernet link and a web browser are highly recommended. In this, case, the OptiLink and OptiLink-II packages are optional
- A milliammeter (milli-ampere-meter), to test the analog outputs.

To perform the procedure in its entirety, a PC computer will be required, along with a proper RS-485 serial interface. Make sure you set your port wiring for either 2-wire (half duplex) or 4-wire (full duplex).

15.3 SOFTWARE DOWNLOADS

These downloads are optional for the 408XT. To perform this procedure completely, you will need either OptiLink or OptiLink-II. The new OptiLink-II software is recommended. Windows Vista or later is required (Windows XP is not supported anymore, sorry). You can download them from the Neoptix website, as follows¹⁴:

To download OptiLink, go to web page <http://neoptix.com/download.asp> and click on the appropriate link. When prompted, enter:

User name: [ftp36681896-8](ftp://ftp36681896-8)

Password: NeolN03?

To download OptiLink-II version 2.4 (for Windows Vista or later), use the same link as above, but select the OptiLink-II link.

Please copy the zip file to a local hard drive and de-compress it before trying to launch the setup.exe.

15.4 TESTING PROBES

We assume here that the utility does not have any spare probes, so we will rely on the probes that are installed in the transformer. The user should know the approximate temperatures inside the transformer; the easiest is to perform this commissioning procedure when the transformer has not had any load for some days, in which case the inside temperature will be approximately the ambient temperature.

Make sure the T/Guard-408 is power on.

¹⁴ The software versions indicated below were current at the time of this writing (July 2015). These links should be adapted to other versions as needed.

Confirm that ALL channels display a temperature that is compatible with the current transformer situation. If no display is available for one or more channels (display: - - - -), confirm that the extension cable is connected for this channel, or confirm with the transformer manufacturer that the corresponding probe was working at the factory. It may happen from time to time that a reading is not available on a probe due to damages caused during transformer manufacturing; if this is the case, you will not be able to get a reading for this channel.

15.5 ANALOG OUTPUT TESTING

Note: A milliammeter will be required to test the analog outputs (4 to 20 mA range).

Note: The factory default for analog outputs is “zero = -100 °C” and “span = 400 °C”; If you are not familiar with these 2 parameters, you should read more about it in this user guide. These defaults can be changed to your liking, by using one of the OptiLink software’s.

You can use the milliammeter to read the current for any channels by connecting it to the corresponding 2 connections on the analog output terminal block. For example, assuming the default settings for the analog channels, you should read 9.0 mA for a temperature of 25 °C; if you have the zero set to “0 °C” and the span to “160 °C”, then you should read 6.5 mA, and so forth.

15.6 RELAY TESTING

The relays can be tested in a number of ways. The easiest way to test them is flip their “Fail Safe” mode status. One needs to do this independently for each relay. For the 408XT, this can be via commands using the web server pages; for the 408, use the OptiLink-II software, page 'Relay conditions'. Upon changing the relay status, observe that the corresponding relay is indeed acting appropriately.

15.7 CONCLUSION

This terminates the commissioning procedure. If you have any questions, do not hesitate to contact Neoptix, support@neoptix.com.

You can perform other functions with the OptiLink software, such as data logging, Modbus communication settings, etc.; refer to the user guide for more information.

16 APPENDIX G – SERIAL COMMAND REFERENCE

You will find below, for reference purposes, a list of all serial commands that can be invoked through the RS485 serial port. These commands are not available through the Ethernet link.

```
b ..... Returns internal instrument temperature
Baud:XXXXXX ... Set baud rate to XXXXXX bit per second, valid rates are:
                9600, 19200, 38400, 57600, 115200 (remember to reconnect)
c:XXXXXXXX ... Clean up (delete) log file XXXXXXXX
d:XXXXXXXX ... Download a temperature log or a protocol pointmap file among:
                [ temperatures.tem / dnp3pt.txt / 60870pt.txt ]
DNP3:b,p,s .... DNP 3.0 serial configuration tool. Usage:
                b (baud)   : 0=9600, 1=19200, 2=38400, 3=57600, 4=115200
                p (parity)  : 0: none, 1: odd, 2: even
                s (stop bits); Example: DNP3:2,0,2
e[1;2;...;n] .. Enable channels to scan; if no argument enable all;
                To disable, use e-[channel number]
f[i;j] ..... Set point adjustment on channel [i] to [j]
format ..... Erase all log file(s)
fx[i] ..... Enable Ethernet 100Base-FX. i=0 for RJ45; i=1 for FX option
gskip[i] ..... Skip up to i (0 to 9) marginal read cycles
h ..... Help menu (this screen)
i ..... Get factory and status Information
j ..... List channel names
j[i]:XXXXXX .. Write channel name for channel # i
key:XXXX-XXX-XX Enter license code to unlock protocols and features
l ..... List log and other information files that can be downloaded using
                the 'd' command
logging[i] .... Logging+ to enable logging, logging- to disable
mb ..... Modbus configuration tool. Usage:
                mb:t,b,p,a
                Where t (type) : 0=RTU (default), 1=ASCII
                b (baud)   : 0=9600, 1=19200, 2=38400, 3=57600, 4=115200
                p (parity): 0=even (default), 1=odd, 2=none
                a (addr)   : 1 to 247 (dec)
                Example: mb:0,1,0,21
                For RTU mode at 19200, even parity, Modbus address 21
n+[i] ..... Toggle calibration (n+e for Neoptix, n+o for Nortech-F)
o[i] ..... Analog out if error (0:Max-Min 1Hz, 1:Max level, 2:Min level)
q ..... upload firmware file from HyperTerminal directory to device
rd ..... Read date, time and time zone
rr ..... Read logging rate
relaydown .... Download relay conditions file
relaystatus ... List of relays, with name and energized status
relayup ..... Upload and apply relay conditions file
resetnet[i] ... Resetnet+ to set networking to DHCP (408XT only)
                Resetnet- to force networking default static IP 10.0.0.4
resetoff ..... Reset temperature offsets to zero
s[i;j] ..... Specify analog output Span [j] for channel [i]
status ..... Download status information file
t[i] ..... Get Temperature reading, channel [i]
u[i] ..... Unit(c= degrees Celsius, f= degrees Fahrenheit)
wd:yyyy/mm/dd Write current date
wr[n] ..... Write logging rate
                n           Logging rate:
                1,2,3,4,5   1,2,5,10,30 sec
                6,7,8,9    1,5,10,30 min
```

10 1 hour
wt:hh:mm Write current time (24 hr format)
wtune[i] Optimize CCD read time (wtune+ to enable, wtune- to disable)
wz:xxx Write time zone (see user guide for complete list of codes)
x[i] Serial mode (1:half-duplex, 2:full-duplex)
y Signal Strength
z[i;j] Temperature [j] for analog output Zero on channel [i]

Serial commands that are specific to smart serial protocols:

Modbus over Ethernet configuration commands:

modbusid:XXX .. Set address id for Ethernet MODBUS (1 to 247, up to 255 is tolerated)

DNP 3.0 serial configuration commands:

DNP3:b,p,s DNP 3.0 serial configuration tool. Usage:
 b (baud) : 0=9600, 1=19200, 2=38400, 3=57600, 4=115200
 p (parity) : 0: none, 1: odd, 2: even
 s (stop bits); Example: DNP3:2,0,2
ethmaster:XXX ..Set Ethernet DNP 3.0 master station addr (normally 65500)
ethsecond:XXX ..Set Ethernet DNP 3.0 secondary station addr (normally 1)
16bitDNP3Set DNP 3.0 protocol to 16 bit mode
32bitDNP3Set DNP 3.0 protocol to 32 bit mode
DNP3configDisplay current DNP 3.0 16 or 32 bit setting
master:XXXXX ...Define serial DNP 3.0 master station addr (default 65500)
second:XXXXX ...Define serial DNP 3.0 secondary station address also
 understood to be 408 slave address (default 1)

IEC 60870-5 configuration commands:

60870:b,a60870-5-101 serial configuration tool. Usage:
 b (baud) : 0=9600, 1=19200, 2=38400, 3=57600, 4=115200
 a (addr) : 1 to 255 (dec); Example: 60870:0,27
eth60870id:XX ..Set address id for Ethernet IEC 60870-5-104 (1 to 255)
60870id:XXXSet address id for serial port IEC 60870-5-101 (1 to 255)

IEC 61850 related commands (and NTP server):

61850secur:XX ..Set Security Mode, can be ON or OFF (Ethernet IEC 61850)
61850ropass:XX .Set password for read only features (Ethernet IEC 61850)
61850lrwpass:XX Set password for limited read-write (Ethernet IEC 61850)
61850crwpass:XX Set password for complete read-write (Ethernet IEC 61850)
NTP:xxxNetwork Time Protocol service (xxx is ON or OFF)
NTPSERVERIP:xx .NTP server ip address (xx must be a valid IP address)
NTPTESTTry synchronizing with configured and enabled NTP server

All commands must be terminated by a carriage return and are case insensitive (i.e. either upper case or lower case can be used for letter characters). Please note, however, that **file names are case sensitive**.

17 APPENDIX H – TIME ZONE LIST

This list is useful when the serial command « wz » is used; see Section 16 for more details on the « wz » command.

Code	Time zone	Code	Time zone	Code	Time zone
1	Africa/Abidjan	63	America/Argentina/Cordoba	125	America/Hermosillo
2	Africa/Accra	64	America/Argentina/Jujuy	126	America/Indiana/Indianapolis
3	Africa/Addis Ababa	65	America/Argentina/La Rioja	127	America/Indiana/Knox
4	Africa/Algiers	66	America/Argentina/Mendoza	128	America/Indiana/Marengo
5	Africa/Asmara	67	America/Argentina/Rio Gallegos	129	America/Indiana/Petersburg
6	Africa/Asmera	68	America/Argentina/Salta	130	America/Indiana/Tell City
7	Africa/Bamako	69	America/Argentina/San Juan	131	America/Indiana/Vevay
8	Africa/Bangui	70	America/Argentina/San Luis	132	America/Indiana/Vincennes
9	Africa/Banjul	71	America/Argentina/Tucuman	133	America/Indiana/Winamac
10	Africa/Bissau	72	America/Argentina/Ushuaia	134	America/Inuvik
11	Africa/Blantyre	73	America/Aruba	135	America/Iqaluit
12	Africa/Brazzaville	74	America/Asuncion	136	America/Jamaica
13	Africa/Bujumbura	75	America/Atikokan	137	America/Jujuy
14	Africa/Cairo	76	America/Atka	138	America/Juneau
15	Africa/Casablanca	77	America/Bahia	139	America/Kentucky/Louisville
16	Africa/Ceuta	78	America/Bahia Banderas	140	America/Kentucky/Monticello
17	Africa/Conakry	79	America/Barbados	141	America/Knox IN
18	Africa/Dakar	80	America/Belem	142	America/Kralendijk
19	Africa/Dar es Salaam	81	America/Belize	143	America/La Paz
20	Africa/Djibouti	82	America/Blanc-Sablon	144	America/Lima
21	Africa/Douala	83	America/Boa Vista	145	America/Los Angeles
22	Africa/El Aaiun	84	America/Bogota	146	America/Louisville
23	Africa/Freetown	85	America/Boise	147	America/Lower Princes
24	Africa/Gaborone	86	America/Buenos Aires	148	America/Maceio
25	Africa/Harare	87	America/Cambridge Bay	149	America/Managua
26	Africa/Johannesburg	88	America/Campo Grande	150	America/Manaus
27	Africa/Juba	89	America/Cancun	151	America/Marigot
28	Africa/Kampala	90	America/Caracas	152	America/Martinique
29	Africa/Khartoum	91	America/Catamarca	153	America/Matamoros
30	Africa/Kigali	92	America/Cayenne	154	America/Mazatlan
31	Africa/Kinshasa	93	America/Cayman	155	America/Mendoza
32	Africa/Lagos	94	America/Chicago	156	America/Menominee
33	Africa/Libreville	95	America/Chihuahua	157	America/Merida
34	Africa/Lome	96	America/Coral Harbour	158	America/Metlakatla
35	Africa/Luanda	97	America/Cordoba	159	America/Mexico City
36	Africa/Lubumbashi	98	America/Costa Rica	160	America/Miquelon
37	Africa/Lusaka	99	America/Creston	161	America/Moncton
38	Africa/Malabo	100	America/Cuiaba	162	America/Monterrey
39	Africa/Maputo	101	America/Curacao	163	America/Montevidео
40	Africa/Maseru	102	America/Danmarkshavn	164	America/Montreal
41	Africa/Mbabane	103	America/Dawson	165	America/Montserrat
42	Africa/Mogadishu	104	America/Dawson Creek	166	America/Nassau
43	Africa/Monrovia	105	America/Denver	167	America/New York
44	Africa/Nairobi	106	America/Detroit	168	America/Nipigon
45	Africa/Ndjamena	107	America/Dominica	169	America/Nome
46	Africa/Niamey	108	America/Edmonton	170	America/Noronha
47	Africa/Nouakchott	109	America/Eirunepe	171	America/North Dakota/Beulah
48	Africa/Ouagadougou	110	America/El Salvador	172	America/North Dakota/Center
49	Africa/Porto-Novo	111	America/Ensenada	173	America/North Dakota/New Salem
50	Africa/Sao Tome	112	America/Fortaleza	174	America/Ojinaga
51	Africa/Timbuktu	113	America/Fort Wayne	175	America/Panama
52	Africa/Tripoli	114	America/Glace Bay	176	America/Pangnirtung
53	Africa/Tunis	115	America/Godthab	177	America/Paramaribo
54	Africa/Windhoek	116	America/Goose Bay	178	America/Phoenix
55	America/Adak	117	America/Grand Turk	179	America/Port-au-Prince
56	America/Anchorage	118	America/Grenada	180	America/Porto Acre
57	America/Anguilla	119	America/Guadeloupe	181	America/Port of Spain
58	America/Antigua	120	America/Guatemala	182	America/Porto Velho
59	America/Araguaina	121	America/Guayaquil	183	America/Puerto Rico
60	America/Argentina/Buenos Aires	122	America/Guyana	184	America/Rainy River
61	America/Argentina/Catamarca	123	America/Halifax	185	America/Rankin Inlet
62	America/Argentina/ComodRivadavia	124	America/Havana	186	America/Recife

Code	Time zone	Code	Time zone	Code	Time zone
187	America/Regina	258	Asia/Hebron	329	Atlantic/Stanley
188	America/Resolute	259	Asia/Ho Chi Minh	330	Atlantic/St Helena
189	America/Rio Branco	260	Asia/Hong Kong	331	Australia/ACT
190	America/Rosario	261	Asia/Hovd	332	Australia/Adelaide
191	America/Santa Isabel	262	Asia/Irkutsk	333	Australia/Brisbane
192	America/Santarem	263	Asia/Istanbul	334	Australia/Broken Hill
193	America/Santiago	264	Asia/Jakarta	335	Australia/Canberra
194	America/Santo Domingo	265	Asia/Jayapura	336	Australia/Currie
195	America/Sao Paulo	266	Asia/Jerusalem	337	Australia/Darwin
196	America/Scoresbysund	267	Asia/Kabul	338	Australia/Eucla
197	America/Shiprock	268	Asia/Kamchatka	339	Australia/Hobart
198	America/Sitka	269	Asia/Karachi	340	Australia/LHI
199	America/St Barthelemy	270	Asia/Kashgar	341	Australia/Lindeman
200	America/St Johns	271	Asia/Kathmandu	342	Australia/Lord Howe
201	America/St Kitts	272	Asia/Katmandu	343	Australia/Melbourne
202	America/St Lucia	273	Asia/Kolkata	344	Australia/North
203	America/St Thomas	274	Asia/Krasnoyarsk	345	Australia/NSW
204	America/St Vincent	275	Asia/Kuala Lumpur	346	Australia/Perth
205	America/Swift Current	276	Asia/Kuching	347	Australia/Queensland
206	America/Tegucigalpa	277	Asia/Kuwait	348	Australia/South
207	America/Thule	278	Asia/Macao	349	Australia/Sydney
208	America/Thunder Bay	279	Asia/Macau	350	Australia/Tasmania
209	America/Tijuana	280	Asia/Magadan	351	Australia/Victoria
210	America/Toronto	281	Asia/Makassar	352	Australia/West
211	America/Tortola	282	Asia/Manila	353	Australia/Yancowinna
212	America/Vancouver	283	Asia/Muscat	354	Brazil/Acre
213	America/Virgin	284	Asia/Nicosia	355	Brazil/DeNoronha
214	America/Whitehorse	285	Asia/Novokuznetsk	356	Brazil/East
215	America/Winnipeg	286	Asia/Novosibirsk	357	Brazil/West
216	America/Yakutat	287	Asia/Omsk	358	Canada/Atlantic
217	America/Yellowknife	288	Asia/Oral	359	Canada/Central
218	Antarctica/Casey	289	Asia/Phnom Penh	360	Canada/Eastern
219	Antarctica/Davis	290	Asia/Pontianak	361	Canada/East-Saskatchewan
220	Antarctica/DumontDUrville	291	Asia/Pyongyang	362	Canada/Mountain
221	Antarctica/Macquarie	292	Asia/Qatar	363	Canada/Newfoundland
222	Antarctica/Mawson	293	Asia/Qyzylorda	364	Canada/Pacific
223	Antarctica/McMurdo	294	Asia/Rangoon	365	Canada/Saskatchewan
224	Antarctica/Palmer	295	Asia/Riyadh	366	Canada/Yukon
225	Antarctica/Rothera	296	Asia/Saigon	367	Chile/Continental
226	Antarctica/South Pole	297	Asia/Sakhalin	368	Chile/EasterIsland
227	Antarctica/Syowa	298	Asia/Samarkand	369	Cuba
228	Antarctica/Vostok	299	Asia/Seoul	370	Egypt
229	Arctic/Longyearbyen	300	Asia/Shanghai	371	Eire
230	Asia/Aden	301	Asia/Singapore	373	Europe/Amsterdam
231	Asia/Almaty	302	Asia/Taipei	374	Europe/Andorra
232	Asia/Amman	303	Asia/Tashkent	375	Europe/Athens
233	Asia/Anadyr	304	Asia/Tbilisi	376	Europe/Belfast
234	Asia/Aqttau	305	Asia/Tehran	377	Europe/Belgrade
235	Asia/Aqtobe	306	Asia/Tel Aviv	378	Europe/Berlin
236	Asia/Ashgabat	307	Asia/Thimbu	379	Europe/Bratislava
237	Asia/Ashkhabad	308	Asia/Thimphu	380	Europe/Brussels
238	Asia/Baghdad	309	Asia/Tokyo	381	Europe/Bucharest
239	Asia/Bahrain	310	Asia/Ujung Pandang	382	Europe/Budapest
240	Asia/Baku	311	Asia/Ulaanbaatar	383	Europe/Chisinau
241	Asia/Bangkok	312	Asia/Ulan Bator	384	Europe/Copenhagen
242	Asia/Beirut	313	Asia/Urumqi	385	Europe/Dublin
243	Asia/Bishkek	314	Asia/Vientiane	386	Europe/Gibraltar
244	Asia/Brunei	315	Asia/Vladivostok	387	Europe/Guernsey
245	Asia/Calcutta	316	Asia/Yakutsk	388	Europe/Helsinki
246	Asia/Choibalsan	317	Asia/Yekaterinburg	389	Europe/Isle of Man
247	Asia/Chongqing	318	Asia/Yerevan	390	Europe/Istanbul
248	Asia/Chungking	319	Atlantic/Azores	391	Europe/Jersey
249	Asia/Colombo	320	Atlantic/Bermuda	392	Europe/Kaliningrad
250	Asia/Dacca	321	Atlantic/Canary	393	Europe/Kiev
251	Asia/Damascus	322	Atlantic/Cape Verde	394	Europe/Lisbon
252	Asia/Dhaka	323	Atlantic/Faeroe	395	Europe/Ljubljana
253	Asia/Dili	324	Atlantic/Faroe	396	Europe/London
254	Asia/Dubai	325	Atlantic/Jan Mayen	397	Europe/Luxembourg
255	Asia/Dushanbe	326	Atlantic/Madeira	398	Europe/Madrid
256	Asia/Gaza	327	Atlantic/Reykjavik	399	Europe/Malta
257	Asia/Harbin	328	Atlantic/South Georgia	400	Europe/Mariehamn

Code	Time zone	Code	Time zone	Code	Time zone
401	Europe/Minsk	457	NZ	513	US/Michigan
402	Europe/Monaco	458	NZ-CHAT	514	US/Mountain
403	Europe/Moscow	459	Pacific/Apia	515	US/Pacific
404	Europe/Nicosia	460	Pacific/Auckland	516	US/Pacific-New
405	Europe/Oslo	461	Pacific/Chatham	517	US/Samoa
406	Europe/Paris	462	Pacific/Chuuk	518	Etc/Zulu
407	Europe/Podgorica	463	Pacific/Easter	520	CET
408	Europe/Prague	464	Pacific/Efate	521	CST6CDT
409	Europe/Riga	465	Pacific/Enderbury	522	EET
410	Europe/Rome	466	Pacific/Fakaofu	523	EST
411	Europe/Samara	467	Pacific/Fiji	524	EST5EDT
412	Europe/San Marino	468	Pacific/Funafuti	525	HST
413	Europe/Sarajevo	469	Pacific/Galapagos	526	MET
414	Europe/Simferopol	470	Pacific/Gambier	527	MST
415	Europe/Skopje	471	Pacific/Guadalcanal	528	MST7MDT
416	Europe/Sofia	472	Pacific/Guam	529	PRC
417	Europe/Stockholm	473	Pacific/Honolulu	530	PST8PDT
418	Europe/Tallinn	474	Pacific/Johnston	531	ROC
419	Europe/Tirane	475	Pacific/Kiritimati	532	ROK
420	Europe/Tiraspol	476	Pacific/Kosrae	533	WET
421	Europe/Uzhgorod	477	Pacific/Kwajalein	534	W-SU
422	Europe/Vaduz	478	Pacific/Majuro	537	Etc/GMT
423	Europe/Vatican	479	Pacific/Marquesas	538	Etc/GMT0
424	Europe/Vienna	480	Pacific/Midway	539	Etc/GMT-0
425	Europe/Vilnius	481	Pacific/Nauru	540	Etc/GMT+0
426	Europe/Volgograd	482	Pacific/Niue	541	Etc/GMT-1
427	Europe/Warsaw	483	Pacific/Norfolk	542	Etc/GMT+1
428	Europe/Zagreb	484	Pacific/Noumea	543	Etc/GMT-10
429	Europe/Zaporozhye	485	Pacific/Pago Pago	544	Etc/GMT+10
430	Europe/Zurich	486	Pacific/Palau	545	Etc/GMT-11
431	GB	487	Pacific/Pitcairn	546	Etc/GMT+11
432	GB-Eire	488	Pacific/Pohnpei	547	Etc/GMT-12
433	Greenwich	489	Pacific/Ponape	548	Etc/GMT+12
434	Hongkong	490	Pacific/Port Moresby	549	Etc/GMT-13
435	Iceland	491	Pacific/Rarotonga	550	Etc/GMT-14
436	Indian/Antananarivo	492	Pacific/Saipan	551	Etc/GMT-2
437	Indian/Chagos	493	Pacific/Samoa	552	Etc/GMT+2
438	Indian/Christmas	494	Pacific/Tahiti	553	Etc/GMT-3
439	Indian/Cocos	495	Pacific/Tarawa	554	Etc/GMT+3
440	Indian/Comoro	496	Pacific/Tongatapu	555	Etc/GMT-4
441	Indian/Kerguelen	497	Pacific/Truk	556	Etc/GMT+4
442	Indian/Mahe	498	Pacific/Wake	557	Etc/GMT-5
443	Indian/Maldives	499	Pacific/Wallis	558	Etc/GMT+5
444	Indian/Mauritius	500	Pacific/Yap	559	Etc/GMT-6
445	Indian/Mayotte	501	Poland	560	Etc/GMT+6
446	Indian/Reunion	502	Portugal	561	Etc/GMT-7
447	Iran	503	Singapore	562	Etc/GMT+7
448	Israel	504	Turkey	563	Etc/GMT-8
449	Jamaica	505	US/Alaska	564	Etc/GMT+8
450	Japan	506	US/Aleutian	565	Etc/GMT-9
451	Kwajalein	507	US/Arizona	566	Etc/GMT+9
452	Libya	508	US/Central	567	Etc/UCT
453	Mexico/BajaNorte	509	US/Eastern	568	Etc/Universal
454	Mexico/BajaSur	510	US/East-Indiana	569	Etc/UTC
455	Mexico/General	511	US/Hawaii		
456	Navajo	512	US/Indiana-Starke		

18 APPENDIX H – ACRONYMS

100BASE-FX	A network topology that use multimode fibers as a communication mean. Bit rate is 100 MB/sec. See http://www.thenetworkencyclopedia.com/entry/100basefx/ .
DHCP	Dynamic Host Configuration Protocol (to automatically assigned IP addresses to computers composing a network). See http://en.wikipedia.org/wiki/Dynamic_Host_Configuration_Protocol
GaAs	Gallium Arsenide (semiconductor). See http://en.wikipedia.org/wiki/Gallium_arsenide . See also http://ecee.colorado.edu/~bart/book/eband5.htm .
ICD file	IEC 61850 related file. ICD = IED Capability Description (file)
IP	Internet Protocol address. See http://en.wikipedia.org/wiki/IP_address
LDAP	Lightweight Directory Access Protocol. See http://en.wikipedia.org/wiki/Lightweight_Directory_Access_Protocol
MTBF	Mean time between failures
NTP	Network time protocol. See www.ntp.org .
SNTP	Simple network time protocol. See http://en.wikipedia.org/wiki/Network_Time_Protocol
SPDT	Single pole double throw (switch)
TCP/IP	Transmission control protocol / internet layer
WTI	Winding Temperature Indicator. See http://electrical-engineering-portal.com/transformer-winding-temperature-thermometer .

19 INDEX

100 Base-FX communication option	31
Acquisition rate in OptiLink-II	71
Acronyms	107
Add a new user, on web page	50
Administrator user role	32
Alarm management	56
Display in home web page	41
Alarm management web page	58
Analog output	
Connections	16
Error mode options	59
Span and zero adjustment, using OptiLink-II	71
Span and zero adjustment, web page	58
Values during power up	17
Wiring	16
Analog outputs	
Testing during commissioning	101
Aramid paper performance	62
Browser memory cache, how to clear	37
Button	
DOWN	18
MENU	18
OK	18
UP	18
Calibration statement	12
Annual re-calibration	12
NIST traceable	12
One-point calibration, using OptiLink-II	72
One-point calibration, using web page	58
Periodicity recommendation	12
Requirements and description	12
CCD integration time verification	24, 87
CE marking	5
Client programs	
ModScan	93
Commissioning procedure	100
Communication options	
100 Base-FX fiber communication	31
Half or Full duplex configuration	99
RS-485 converter	99
RS-485 interface	99
Compatible Internet browsers	35
Configuration	
Recommendations for transformer applications	86
Configuration files	49
Configuring relays	56
Connectors, inputs / outputs	17
Console, in OptiLink	83
Data logging	See Logging
Date	
How to set time zone in OptiLink-II	73
How to set time zone in web page	43
Debugging serial port with LED feedback	21
Delete log file	
Using OptiLink-II	73
Using web page	52
DHCP Server for Windows, software	34
Dielectric materials	11
Display	
Interval between 2 LED banks, if more than 8 channels ...	21
Multiplexing 1-8 and 10-16 channels	14
DNP 3.0 protocol	11
16 and 32 bit support	47, 74
Selection in OptiLink-II	75
Selection in web page	44
How to configure, using OptiLink-II	75
How to configure, with browser	47
How to configure, with OptiLink-II	74
Serial configuration commands	103
Download	
Event log	57
Download or delete page, data logging	
Using OptiLink-II	73
Using web page	52
Downloading files	
Relay condition file	49
Status file	49, 73
System files	49
User guides	49
Drift, none with GaAs technology	11
Electrical installation	14
Ethernet communication statistics	42
Ethernet communication, 100 Base-FX	31
Ethernet protocols, how to enable	45, 74
Event log download	57
Event logging, in memory	27, 56
Extension cables	
Do not cross connect	16
Installation	16
Serial numbers simplify installation	16
Fiber optic probe care	5
Fiber optic probe repair issues	11
File uploading and downloading	See Downloading files
Firmware	
Upload procedure, using OptiLink-II	75
Upload procedure, via web interface	78
G1009 probe installation guide	11
GaAs technology	11
Global temperature display	41
Graphing rate in OptiLink-II	71
Graphing, using OptiLink-II software	71
Guest, role definition	62
Hardware fault, relay	14, 15
Hardware reference	
Mating connectors	17
Heat run tests	11
High global temperature	
On display	23

On web page.....	41	Logging rate in OptiLink-II.....	71
ICD file download, with IEC 61850.....	47	Low global temperature	
IEC 60870-5-101 serial protocol.....	48, 75	On display.....	23
IEC 60870-5-104 Ethernet protocol.....	48, 74	On web page.....	41
IEC 61850 protocol		Manage web users.....	50
How to configure, using OptiLink-II.....	74	Mating connector definition.....	17
How to configure, using web page.....	46	Mating connectors (power in and analog outputs).....	14
ICD file download.....	47	Mating connectors (ST optical inputs).....	15
Password management.....	46	Menu, via keypad.....	See Keypad menu
Installation		Modbus protocol.....	11
Electrical installation.....	14	Configuring, on a serial port.....	88
Extension cables.....	16	Exception codes.....	93
Mating connectors (electrical).....	14	Function Codes and Register Addresses, on serial port.....	89
Mating connectors (ST optical inputs).....	15	How to configure, with browser.....	48
Mechanical specifications.....	13, 14	How to configure, with OptiLink-II.....	74
ModScan.....	93	How to use ModScan over Ethernet.....	94
Mounting on swing panel.....	14	Legacy register support.....	89
OptiLink.....	81	ModScan client application.....	93
OptiLink-II.....	68	Monitoring multiple instruments.....	95
RS-422 RS-485 communication converter.....	99	Neoptix support For.....	88
Insulation material remaining life.....	60	RS-485 converter.....	99
Internet browsers.....	35, 37	RTU serial transmission mode.....	88
Interpretation of probe signal intensity.....	86	RTU Transmission Mode.....	89
Interval between display of 2 LED banks.....	21	Testing RS-485 serial port.....	21
IP address		Modify main user role web page.....	51
How to set in Windows.....	33	ModScan	
Static address.....	33	Data logging.....	96
Kerosene desorption.....	11	How to use for Modbus over Ethernet.....	94
Keypad menu		Modbus testing.....	93
Channel Enable.....	24	Using the trial version.....	96
DNP 3.0 protocol setting.....	29	MTBF of light source.....	11
Entry point.....	18	Network configuration.....	33
Ethernet menu (408XT only).....	30	NIST traceable calibration.....	12
IEC 60870-5-101 protocol setting.....	29	Nomex paper performance.....	62
Main (top level).....	18	NTP servers, for time synchronization	
Minimum-maximum temperatures.....	23	Using OptiLink-II.....	73
Modbus protocol setting.....	29	Using web page.....	43
Neoptix ASCII protocol.....	29	Offset, on an optical channel	
Relay Condition settings.....	26	Entering with OptiLink-II.....	72
Relay failsafe setting.....	27	Entering with web page.....	58
Second calibration enable.....	21	Oil immersion.....	11
Serial protocol menu set up.....	28	One-point calibration	
Setup, general parameters.....	21	Using OptiLink-II.....	72
Signal level on probes.....	24	Using web page.....	58
Temperature.....	23	Optical channel setting	
Timeout.....	18	Using OptiLink-II.....	71
Kraft paper performance.....	62	Web page.....	58
Log download or delete page		OptiLink.....	81
Using OptiLink-II.....	73	Chart.....	85
Using web page.....	52	Console.....	83
Log setting page.....	54	Logging to an Excel file.....	84
Log viewer page.....	53	Using.....	81
Logging		Viewing temperature data.....	85
In Windows, with OptiLink.....	83	OptiLink-II software package	
Start of new log file.....	21	Acquisition vs. Graphing rates.....	71
Synchronization time, with NTP server.....	43, 73	OptiLink-II software package.....	68
Using ModScan (Modbus).....	96	Acquisition vs. Logging rates.....	71

Com port selection	69	RS-232 interface	
Graphing	71	RS-422 RS-485 communication interface	99
Logging to an Excel file	70	RS-485 to USB converter	99
Option setting.....	71	RS-232 to RS-485	
Troubleshooting	75	converters	
Viewing temperature data	69	Comment on maximum cable length.....	76
Options		RS-232 to RS-485 converters	99
OptiLink-II graphing	71	RS-485 interface	15, 99
Overview page		Comment on maximum cable length	76
Channel parameters	58	Testing with LED feedback	21
Relay conditions	54	Wiring in half or full duplex.....	29
Paper performance		Serial port	
Aramid paper.....	62	Comment on maximum cable length.....	76
Kraft paper.....	62	How to set half or full duplex, using the keypad.....	21
Nomex paper	62	How to set half or full duplex, using the web interface	44
Period between display of 2 LED banks	21	Testing with LED feedback	21
POSIX time definition	53	Wiring in half or full duplex.....	29
Power consumption.....	11	Serial protocol enabling	
Private network configuration	33	Using OptiLink-II	75
Probe Installation Guide	11	Using web page	44
Probe installation guide, g1009	12	Signal Strength, how to get using serial commands.....	86
Probe testing		Smart grid	
Measuring optical signal strength	24	Ethernet protocols, how to enable	45, 74
Probes		Smart Grid.....	11
Extension cable installation	15	Software	
Installation of extension cables	15	Apple Safari browser	35
Outside connections.....	16	DHCP SVR (DHCP server).....	34
Testing during commissioning.....	100	Download for commissioning.....	100
Protocol		Google Chrome browser	35
DNP 3.0 protocol setting, with keypad.....	29	Microsoft Internet Explorer browser	35
Enabling Ethernet protocols	45, 74	ModScan application.....	93
IEC 60870-5-101 protocol setting, with keypad	29	Using the trial version	96
Modbus protocol setting, with keypad	29	Mozilla Firefox browser.....	35
Neoptix ASCII settings, with keypad	29	OptiLink	81
Serial protocol enabling, using OptiLink-II.....	75	OptiLink-II	68
Serial protocol enabling, using web server.....	44	Software download, for commissioning.....	100
Switching protocol, using keypad.....	29	Software upgrade	
Qgateway.icd file download, IEC 61850.....	47	Procedure using OptiLink-II	75
Quick Startup Guide.....	13	Procedure via web interface	78
Real-time clock.....	11	Specifications	
NTP servers.....	43, 73	Input voltage	5
Relay		Mechanical installation	13, 14
Behavior during booting time.....	15	Statistics, Ethernet communication.....	42
Fail safe mode.....	54	Status information file	
System fault relay	14, 15	Download using OptiLink-II	73
Testing during commissioning	101	Download using web page	49
Relay condition		Example of file content	79
An example	56	System fault relay	14, 15
Keypad menu.....	27	System label setup.....	43
Setting using OptiLink-II.....	72	TCP/IP Ethernet protocol.....	11
Setting using page, web.....	55	Temperature acquisition rate in OptiLink-II	71
Relay connection		Temperature display	
Condition setting	55	Global values	41
Time delay relay	54	Inside T/Guard enclosure	41
Relay setup page.....	72	Temperature logging	See Logging
Relay trigger	27	Testing serial port with LED feedback	21
Return Authorization Number (RMA)	10	Time	

List of time zones.....	104	User guides, how to download.....	49
NTP server setup, using OptiLink-II.....	73	User management	
NTP server setup, using web page.....	43	Guest or Administrator	32
Setting up in OptiLink-II	73	Modify user role, web page	51
Web setup page.....	43	User management, on web page.....	50
Time delay relay, for fail safe mode.....	14, 15, 54	Users, how to configure using User Page	50
Time delay relay, to use with the fault relay	14, 15	Vibration resistance.....	11
Time zone		Visual background image file.....	60
Complete list.....	104	Warning	
Setting up in OptiLink-II	73	Do not cross-connect extension cables.....	16
Web setup page.....	43	Offset on optical channel	58, 72
Transformer application		Using termination resistors on a RS-485 bus	99
Configuration example	56	Wiring in half or full duplex.....	29
Transformer application documentation.....	12	Warranty	
Transformer applications		Agreement.....	10
Configuration recommendations	86	Limitations on probes.....	10
Transformer Life.....	See TransLife™	Web browser	11, 32
TransLife		Web user management	50
Web, result page	60	Windows Device Manager	75
Web, setup page.....	61	WinTech Software	98
Troubleshooting		Write logging rate.....	73
OptiLink-II	75	Wtune	
Upload file		How to set with OptiLink-II.....	72
Configuration file, etc., with web page	49	How to set with the keypad	21
Transformer background image file	60		

Neoptix Canada LP
A Qualitrol LLC Company
1415, rue Frank-Carrel, Suite 220
Québec City, QC
CANADA G1N 4N7

Tel: 418-687-2500
Fax: 418-687-2524
www.qualitrolcorp.com
www.neoptix.com
support@neoptix.com

Printed in Canada